

TotalPass® P400

User Guide



Copyright © 2020 IconTime. All rights reserved.

Reproduction of this document in whole or in part is strictly prohibited. This document may contain typographical or copy errors. TotalPass, IconTime, the IconTime logo, and all other IconTime product names mentioned in this document are registered trademarks of IconTime.

IconTime

9000 SW Gemini Drive, Bldg. 8
Beaverton, OR 97008

Contact Support: 1-800-847-2232 #1

Contact Sales: 1-800-847-2232 #3

www.icontime.com

Table of Contents

Chapter 1: Getting Familiar with Your Time Clock.....	7
Everything you need to get your time clock up and running:	7
System Requirements.....	8
Features.....	8
Available TotalPass Upgrades.....	8
Connection / Setup	9
Logging In.....	9
Support and Troubleshooting	10
Integration with Payroll	10
Register your Time Clock.....	10
Navigating the Time Clock Software	10
Home Page.....	11
Lists Menu	11
Reports Menu.....	11
Payroll Menu.....	11
Files Menu.....	12
Settings Menu	12
Help Menu	12
Chapter 2: Setting Your Time Clock Preferences.....	13
Setting Your Pay Preferences	13
Setting Your Overtime Preferences	14
Setting Your Punch Preferences	14
Setting Your Device Preferences	16
Setting Your Alert Preferences (Requires Upgrade)	17
Alert Setup.....	18
Creating Custom Fields.....	18
Chapter 3: Setting Up Your Employees	20
Employee List.....	20
Make Employees Inactive.....	20
Customizing the Columns	20
Time Remaining Before Overtime.....	20
Adding Employees.....	21
Employee Information	21
Employee Settings	21
Entry Method	21
Lunch Time Deduction	22
Delete Employee's Punches.....	22

Chapter 4: Clocking In and Out.....	23
Time Clock Keypad Functions	23
Punching In and Out.....	23
Keypad PIN Entry	24
Proximity Badge Entry.....	24
Web Punch Entry	24
Tracking Paid Breaks	24
To transfer out of the break department and back to work:	24
Chapter 5: Generating Reports.....	25
Reports Overview	25
Adding a Punch.....	25
Adding Non-Work Hours (Holiday and Non-Worked)	26
Editing a Punch	27
Using Batch Edits.....	27
Viewing Additional Reporting Details.....	27
Using the Attendance Report	28
Using the Timecard Report	29
Chapter 6: Sending to Payroll	30
Create Payroll Export File.....	30
QuickBooks Export Payroll process.....	31
Configuring Payroll	32
QuickBooks Online Configuration.....	32
Chapter 7: Alternate Employee Entry Options.....	34
Using Proximity Badges.....	34
Assigning Proximity Badges to an Employee.....	34
Punching In/Out Using Proximity Badges	34
Web Punch Entry (Web Punch License purchase required).....	35
Locking the Time Clock Terminal Keypad	35
Setting Up Your Employees for Web Punch	35
Punching In/Out Using Web Punch	35
Clocking In/Out using GPS Location Tracking.....	36
IP Address Restriction.....	37
Setting Authorized IP Addresses by Employee.....	37
Running Reports with Web Punch.....	38
Chapter 8: Maintaining Your Time Clock	39
Creating a Data Backup	39
Data Backup from the Software Interface.....	39
Data Backup to a USB Flash Drive	39
Restore Time Clock Data Backup.....	40

Restore a Time Clock Data Backup from the Software Interface	40
Restore a Time Clock Data Backup from a USB Flash Drive	40
Removing Data from Your Time Clock	41
Updating Your Time Clock.....	41
Updating Your Time Clock from the Software Interface.....	41
Updating Your Time Clock Using a USB Flash Drive	42
Auto-Update	42
Resetting Your Time Clock Password.....	43
Changing Your Time Clock Software Interface Password.....	43
Resetting the Software Interface Password	43
Resetting the Supervisor Mode Security Code	44
Chapter 9: Time Clock Terminal Supervisor Mode	45
Log Into Supervisor Mode	45
Parent Clock Supervisor Mode Settings	45
View IP Address	45
Network Settings	45
LAN Settings.....	45
Wi-Fi Settings	46
Assign Badges	46
Set Date/Time.....	46
View Serial #	46
View Version #	47
Download Backup.....	47
Restore Backup	47
Enable Upgrade.....	47
Reset Password	47
Erase All Memory	47
Download Log	47
Chapter 10: Connecting to the Clock	48
Wi-Fi Connection.....	48
Connecting Using the Clock Interface	48
Connecting Using a WPS Button.....	49
Connecting Using a WPS with PIN.....	49
Connect to the Wireless Network	50
Connecting Using the Software Interface	50
Ethernet Connection	50
Chapter 11: Software Upgrades	52
Enabling Software Upgrades.....	52
Employee Capacity Upgrades.....	52

Benefit Tracking Upgrade	53
Benefit Tracking and Accruals	53
Enhanced Overtime Preferences	53
Revision Zones.....	53
Enhanced Overtime Preferences	53
Non-Worked Hours and Benefit Time (Vacation, Sick, Personal)	53
Customizing Benefit Accrual Rules.....	54
Accrual Summary Report	55
Revision Zones	55
Email Alerts Upgrade	56
Outgoing Email Settings (SMTP Server).....	56
Common SMTP Server Settings.....	58
Chapter 12: Configure for Remote Access	59
System Requirements.....	59
Step 1: Set Up the TotalPass on the Local Network	59
Step 2: Router Configuration	59
Assign a Static IP Address to the Time Clock	60
Set Up Port Forwarding on the Router	60
Step 3: Connect to Your TotalPass Clock over the Internet	61
Remote Connection Frequently Asked Questions.....	62
Troubleshooting Remote Connection Problems.....	62
Standard Remote Connection Setup Diagram.....	64
Connect Clocks Remotely with Multi-clock Diagram	64
Warranty Information	65
FCC Part 15	67

Chapter 1: Getting Familiar with Your Time Clock

Everything you need to get your time clock up and running:

- ✓ Connecting your time clock and logging in for the first time
- ✓ How to get help
- ✓ Navigating through the software

Welcome

Thank you for choosing IconTime. We appreciate your business.

Our mission is to provide our customers with quality products and excellent customer service. We pride ourselves on being innovators in the time and attendance industry, developing products that are easy to install, simple to operate, and reliable.

The TotalPass P400 system offers breakthrough web-enabled technology that brings the simplicity of embedded software to your time and attendance system, without requiring Internet access.

This guide will help you set up the clock and use the many features to automate time and attendance, streamline your payroll process, and generate reports that provide insight into labor costs.

System Requirements

For Network Access to the Time Clock

- Any Web browser on PC, Mac, tablet, or smartphone
- An available Ethernet port or wireless network
- Remote Internet access also requires Internet and port forwarding to port 9844 or port 80.

For Direct Connection to the Time Clock

- Use any Web browser on a PC or Mac where the time clock is directly connected to the computer.
- USB port on Windows PC or Ethernet port on Windows PC or Mac

Payroll Export Utilities

- Paychex Flex, SurePayroll, Paychex Preview, Paycom, Paylocity, ADP Workforce Now, and QuickBooks Online exports are compatible with all operating systems.
- Windows Vista or above required for QuickBooks Plug-in* and the ADP Export.

* Only available with QuickBooks desktop versions.

Internet Connection Required for the following functionality:

- Email alerts, backups, or payroll reports
- Connecting multiple time clocks together
- Accessing the time clock from more than 1 computer (Network connection required)

Features

The **TotalPass P400** was designed to streamline the time and attendance and payroll process. The TotalPass software is built into the time clock and provides a wealth of features to save you time and improve accuracy.

- Capacity of 25 employees and upgradeable to 250 employees
- Pre-assigned employee PIN numbers included. Optional upgrades include Custom PIN Entry (4-9 digits), Proximity Badges (sold separately), and Web Punch (sold separately).
- Configurable for remote Internet access
- Paid break tracking
- Export to QuickBooks, ADP, Paychex Flex, Paychex Preview, SurePayroll, Paycom, or CSV
- Automatic lunch time deduction
- Timecard, Attendance reports
- Enter Holiday and NonWorked Hours for one or more employees

Available TotalPass Upgrades

Benefit Tracking and Accruals

This upgrade allows you to automatically calculate vacation, sick, and personal time off.

Customize accrual rates and tracking per employee for maximum policy flexibility.

Upgrade Employee Capacity

Expand your system with your business; upgrade the employee capacity from the standard 25 employees to 50, 100, or 250 employees.

Employee Web Punch Entry

Provide employees with a contact-free option to punch In / Out using a web browser on their computer, smart phone, or tablet.

Web Punch Entry licenses are available in sets of 5 and can be re-assigned to new employees as needed. The time clock has a maximum capacity of 50 Web Punch licenses.

Email Alerts Upgrade

Automatically email you alerts as employees come and go, before they accumulate overtime, and more. It also allows the Timecard report and backups to be emailed to one or more recipients. The email server settings have to be configured for emails to be sent out.

Advanced Pack Upgrade

The Advanced Pack upgrade includes:

- Additional capacity to accommodate another of 25 employees, bringing the total system capacity to 50
- Department tracking and reports
- Supervisor logins, permission levels, and employee assignments
- Track notes by the punch, employee, or department
- Customized reports
- Customized employee ID (PIN) numbers
- Customized system prompts
- Employee input fields
- Connect multiple time clocks using the Multi-Clock feature
- Employee Web browser entry (for 5 Web Punch Licenses)

Connection / Setup

Refer to the TotalPass [Quick Start Guide](#) for instructions on setting up your employee time clock's connection and logging into your time clock for the first time.

Logging In

To log in and view employee information and punch details, enter the time clock's assigned Internet Protocol (IP) address into your internet browser address field.

You must enter the address exactly as displayed below. For example, if the assigned address is 192.168.2.103, enter that text directly into the address field, preceded with **http://**.



Note: If you are logging in using USB, navigate to <http://totalpass.timeclock> or enter <http://172.20.20.1> as the IP address.

Support and Troubleshooting

For your convenience, troubleshooting tips and how-tos can be found on our technical support site at www.support.icontime.com.

This system includes a 30-day trial of our [TotalPass P400 Customer Care Pack](#) which includes unlimited telephone, email, and remote assistance support. Support can be reached Monday through Friday from 7:30am to 4:30pm (PST) at (800) 847-2232 option 1 or via email at support@icontime.com.

Integration with Payroll

Built-in Exports

Your time clock includes a Paychex Flex, Paychex Preview, SurePayroll, Paycom, Paylocity, ADP Workforce Now, QuickBooks Online, and QuickBooks (Pro, Premier, Enterprise) export formats. It also includes a CSV Export option used for viewing time clock data in Excel or importing into other third-party payroll programs.

Desktop Installed Export Utilities

Exporting time clock data to PC versions of QuickBooks or ADP requires the installation of an export utility program. Select the appropriate link below.

- **QuickBooks** – www.icontime.com/software/QB_Plug-in_Import.exe
- **ADP** – www.icontime.com/software/ADP_Export_1.0.12.exe

Register your Time Clock

The first time you log in to your time clock you will be prompted to register it. [Register your time clock](#) to ensure that you receive email notification of free software updates, your manufacturer's 1-year hardware warranty, and 30 days of free technical support.

Navigating the Time Clock Software

The time clock interface is designed to allow you to quickly and easily complete your tasks and run your reports. In this section you will learn how to navigate through your time clock application. Application navigation is done through six distinct menus: Home, Lists, Reports, Files, Settings, and Help. Moving your cursor over each icon displays the individual drop-down menu items.

Sort By - Show All

Ignore	Date / Time	Alert / Task
<input type="checkbox"/>	10/05/20 Mon 12:00 a	New pay period started
<input type="checkbox"/>	09/21/20 Mon 12:00 a	New pay period started
<input type="checkbox"/>	09/14/20 Mon 12:00 a	New pay period started
<input type="checkbox"/>	09/08/20 Wed 01:56 p	View/Print Your User Guide
<input type="checkbox"/>	09/08/20 Wed 01:56 p	Setup Your Pay Period
<input type="checkbox"/>	09/08/20 Wed 01:53 p	Setup Your Employees

Submit Cancel



TotalPass™ P400 Time Clock, Copyright® 2016-2020, Icon Time Systems, Inc.
DISCLAIMER

Home Page

When you first log into your time clock application, the Home page displays automatically. The Home page provides a quick glance at the activity on your time clock, including notifications of custom alerts. The Home page also contains helpful links to configure your software.

Current Alerts

The Home page displays important system alerts and time clock activity alerts. For instructions on customizing your alert settings, refer to [“Setting Your Alert Preferences \(Requires Upgrade\)”](#) in Chapter 2.

When you no longer want to be notified of a particular task or alert, check the box next to that item in the **IGNORE** column, and click **Submit**. If you would like to see past alerts, click **Show All**. To view the details of the alert, click the alert link in the **ALERT/TASK** list.

Lists Menu

Use the Lists menu for adding, modifying or deleting employees, departments, supervisors, or enabling or disabling additional time clocks connected to the system.

For instructions on setting up employees, refer to: [“Chapter 3: Setting Up Your Employees”](#).

Reports Menu

Your time clock comes with four reports that make it quick and easy to get the information you need to complete your work and process payroll. Use the Reports menu to access the reports. For additional information on generating and customizing reports, Refer to [“Chapter 5: Generating Reports”](#).

Payroll Menu

The Payroll menu allows you to create exports of your time clock data to be imported you're your payroll program for streamlining payroll day. In addition, within the Payroll menu, find options to email the timecards to individual employees or as one report, to a manage. For additional information on sending your time clock data to payroll, Refer to [“Chapter 5: Generating Reports”](#).

Files Menu

Use the Files menu to back up data, restore data back-ups, Delete Old Punches, and update your employee time clock.

Settings Menu

Use the Settings menu to customize your payroll, overtime, punch, device, and alert preferences. Before running any reports, set your preferences as described in [Chapter 2: Setting Your Time Clock](#) Preferences.

Help Menu

The Help menu gives you quick access to the Help Center and to view the About Your Clock page for your time clock.

Chapter 2: Setting Your Time Clock Preferences

Before accurate reports can be generated and employee punch details are calculated correctly, you must set your time clock rules and preferences:

- ✓ Set up your pay period and overtime rules
- ✓ Set up punch rounding
- ✓ Set up Alert Preferences

Setting Your Pay Preferences

There are two ways to access your Pay Preferences:

- Click **Setup Your Pay Period** in the Alert/Task list
- Select **Preferences** from the Settings menu.

Follow the instructions below to set your Pay Preferences.

- Complete the **Company Name** field and, if applicable, the **Company Payroll ID** field. These will be used when emailing time.
- Select the applicable option from the **Pay Period Type** drop-down menu:
 - o **Weekly** - Employees are paid once per week
 - o **Bi-Weekly** - Employees are paid every two weeks
 - o **Semi-Monthly** - Employees are paid twice per month
 - o **Monthly** - Employees are paid once per month
- If you select the semi-monthly pay period, two additional date fields display that must be completed.
 - o Type the first day of the month that your pay period begins in the **Start Semi-Monthly on** field.
 - o Type the second day of the month that your pay period begins in the **and on** field.
- Click in the **Last Pay Start** field to open the calendar and select the date that your previous pay period started.

The screenshot shows the 'Pay' tab selected in a navigation bar with other tabs: Punch, Device, Alerts, and Custom Fields. The form is divided into two sections: 'COMPANY INFORMATION' and 'PAYROLL PREFERENCES'. Under 'COMPANY INFORMATION', there are input fields for 'Company Name' and 'Company Payroll ID'. Under 'PAYROLL PREFERENCES', there is a 'Pay Period Type' dropdown menu currently set to 'Weekly'. Below this are three date fields: 'Last Pay Start' (08/05/18), 'This Pay Start' (08/12/18), and 'Next Pay Start' (08/19/18). At the bottom, there is a 'Day Start' field set to '12:00a' with up and down arrows, and a 'Week Start' dropdown menu currently set to 'Sun'.

Tip: Use the << and >> arrows to select the year. Use the < and > arrows to select the month.

- Click in the **This Pay Start** field to open the calendar and select the date that your current pay period started.
- Click in the **Next Pay Start** field to open the calendar and select the date that your next pay period will start.
- Type the time of day that your workday begins in the **Day Start** field. You only need to modify this setting if your company has a 24-hour work schedule and needs to accommodate

overnight shifts; it is recommended that this setting remain at 12:00am.

- Select the day of the week that your work week begins from the **Week Start** drop-down menu. The company's weekly overtime calculations are based on this setting.

Setting Your Overtime Preferences

Your Overtime Preference settings are on the **Pay** tab under **Payroll Preferences**. The TotalPass comes with two levels of daily and weekly overtime and consecutive day overtime.

Follow the instructions below to set your Overtime Preferences.

1. To set daily overtime rules, type the number of hours an employee must work in one day before they receive overtime pay in the **Day OT1 After** and the **Day OT2 After** fields as required. If your company does **not** pay daily overtime, type **99**.
2. To set weekly overtime rules, type the number of hours an employee must work in one week before they receive overtime pay in the **Week OT1 After** and the **Week OT2 After** fields as required. If your company does **not** pay weekly overtime, type **99**.

OVERTIME PREFERENCES

Day OT1 After	<input type="text" value="8.00"/>	Hours
Day OT2 After	<input type="text" value="99.00"/>	Hours
Week OT1 After	<input type="text" value="40.00"/>	Hours
Week OT2 After	<input type="text" value="99.00"/>	Hours
Consecutive Day OT	<input type="text" value="No"/>	
OT1 Multiplier	<input type="text" value="1.50"/>	
OT2 Multiplier	<input type="text" value="2.00"/>	

Note: Overtime (OT1) is calculated at time-and-a-half (1.5) the rate of pay and double overtime (OT2) is calculated at two times the rate of pay (2.0). With the Benefit Tracking Upgrade, these rates can be customized.

3. To set consecutive day overtime rules, change the **Consecutive Day OT** drop-down menu to **Yes**. This option will pay OT1 and/or OT2 on the seventh consecutive day of work, regardless of hours worked during the work week. This rule is most commonly used by unions and in California. If your company does not pay consecutive day overtime, change the **Consecutive Day OT** drop-down menu to **No**.

Note: Making a change to the overtime options prompts the time clock to restart. Doing so will make the time clock unavailable until the clock fully reboots.

- ✓ Click **Submit** to save your settings and return to the Home page.

Setting Your Punch Preferences

Select **Settings | Preferences** and click on the **Punch** tab. The Punch Preferences section displays.

Note: The rounding rule selected affects all punches system wide. The original punch time remains unchanged on the employee time card. The punch(shift) hours round according to the rounding rules set.

Follow the instructions below to set your Punch Preferences.

- Select the applicable rounding type from the Rounding Type drop-down menu.

- None (No Rounding):** Accumulates 100% of all time registered on the clock.
- 15 Minute (7/8 Rounding):** Rounds and calculates punches to the nearest quarter hour (15 minutes). The split occurs in the middle of each quarter hour.

To illustrate: An In punch of 7 minutes 59 seconds *rounds back*
An In punch of 8 minutes 00 seconds *rounds forward*

Example: An In punch of 7:52 a.m. would calculate as 7:45 a.m.
An In punch of 7:53 a.m. would calculate as 8:00 a.m.

- 15 Minute Slant (10/5 In, 5/10 Out):** Quarter hour rounding similar to above except the break point occurs on the 5th minute or 10th minute depending on whether it is an In punch or an Out punch.

To illustrate: An In punch of 4 minutes 59 seconds *rounds back*
An In punch of 5 minutes 00 seconds *rounds forward*
An Out punch of 9 minutes 59 seconds *rounds back*
An Out punch of 10 minutes 00 seconds *rounds forward*

Example: An In punch at 7:49 a.m. would calculate as 7:45 a.m.
An In punch at 7:50 a.m. would calculate as 8:00 a.m.
An Out punch at 4:49 p.m. would calculate as 4:45 p.m.
An Out punch at 4:50 p.m. would calculate as 5:00 p.m.

- 10th Hour:** Rather than rounding the punch hours, this selection calculates punches from the tenth hour point and advances each six minutes.

Minutes 10 th	Minutes 10 th
00-05 = .0	30-35 = .5
06-11 = .1	36-41 = .6
12-17 = .2	42-47 = .7
18-23 = .3	48-53 = .8
24-29 = .4	54-59 = .9

To illustrate: An In punch from :00 minutes after the hour to :05 after the hour rounds to the top of the hour (.0).
An In punch from :30 minutes after the hour to :35 minutes after the hour rounds to .5.

Example: An In punch at 7:30 a.m. would calculate at 7.5 a.m.

An Out punch at 4:05 p.m. would calculate as 4.0 p.m.

- The **Automatic Punches become IN at** field automatically makes the next punch an In punch after a determined number of hours. This option is convenient if an employee forgets to punch Out.

This option is only used when an employee entry method is set to Automatic. Refer to [Chapter 3: Setting Up Your Employees](#), for additional information.

- Check the **Flag edits on reports** checkbox to flag manually edited punches on reports. If checked, all edited punches are marked with **E**.
- Type the number of minutes in **Reject Like Punches within** to reject the same type of punch at the time clock, within the minutes specified. The second punch is ignored.
- Click **Submit** to save your settings and return to the Home page.

Note: Making a change to the rounding options will prompt the time clock to restart. Doing so will make the time clock unavailable until the clock fully reboots.

Setting Your Device Preferences

Select Settings | Preferences and click on the Device tab to go to the Device Preferences screen. Important information such as your Database Version, Software Version, and time clock serial number will appear at the top of this section

Follow the instructions below to set your Device Preferences.

- Select to display minutes on your reports in decimal or hh:mm (minutes) format from the **Calculated Time Format** drop-down menu.
- Check the **Hide Employee PIN** checkbox to hide employee PINs (ID numbers) at the time clock terminal, preventing coworkers from viewing another employee's PIN.
- Type a unique 6-digit security code in the **Supervisor Code** field to secure the employee time clock.

DEVICE PREFERENCES

Calculated Time Format: **Hundredths** ▼

Hide Employee PIN: ☐

Supervisor Code:

Lock Keypad: ☐

Use Daylight Savings: ☒

Default Attendance Report To: **Today** ▼

Default Timecard Report To: **This Pay** ▼

Refresh Home Page Every: Minutes

Use Popup Windows for Edits: **Yes** ▼

Show total hours at the clock: ☒

Important: You need this code to access Supervisor Mode on the employee time clock. The default supervisor code is 00 00 00.

- Check the **Lock Keypad** checkbox to lock the keypad and prevent keypad entry of employee ID numbers (PIN) at the employee time clock. Use this option if you purchased proximity badges and you do not want employees using the keypad.
- Check the **Use Daylight Savings** checkbox if you want the time clock to automatically adjust time for daylight savings.
- Select the default time frame to view the Attendance Report screen from the **Default Attendance Report To** drop-down menu.

- Select the default time frame to view the Timecards Report screen from the **Default Timecard Report To** drop-down menu.
- Type the number of minutes to refresh the alerts on the Home page in the **Refresh Home Page Every** field. If your system runs slow, type a larger number for the refresh time.
- Use **Popup Windows for Edits** includes 3 options:
 - **Yes** - have a separate pop-up window display when editing a punch in a report screen.
 - **Yes with Batch Edits** – uses the pop-up window described above. Report will not refresh with each change submitted. You must refresh the page to see the report with the edited punches.
 - **No**
- Check the **Show total hours at the clock** checkbox to display the employee's total daily hours after the employee punches out.
- Click **Submit** to save your settings and return to the Home page.

Multi-clock Preferences: Multi-clock refers to multiple time clocks connected together to share one database. For additional information on setting up multi-clock preferences, refer to

[Chapter 13: Multi-clock Configuration.](#)

Setting Your Alert Preferences (Requires Upgrade)

- Select **Settings | Preferences** and click on the **Alert** tab to setup the alert notices displayed on the Home page. The Home page updates based on your time setting for the **Check Alerts Every** field described below.
- Type the least amount of hours an employee can work per shift in the **Alert Low Hours at** field. If an employee works fewer hours than is specified, an alert generates. To disable this alert, set the alert value to **0**.

ALERT PREFERENCES		
Alert Low Hours at	<input type="text" value="0.00"/>	Hours per punch
Alert High Hours at	<input type="text" value="14.00"/>	Hours per punch
Maximum Punch Time at	<input type="text" value="40.00"/>	Hours per punch
Alert Day Overtime OT at	<input type="text" value="2.00"/>	Hours remaining
Alert Week Overtime OT at	<input type="text" value="8.00"/>	Hours remaining
Check Alerts Every	<input type="text" value="15"/>	Minutes
Email Alerts Every	<input type="text" value="15"/>	Minutes
Update Employee Hours Every	<input type="text" value="15"/>	Minutes
Email Daily Alerts at	<input type="text" value="12:00a"/> ▲ ▼	

- Type the amount of hours an employee can work per shift in the **Alert High Hours at** field. If an employee works a shift more than the hours specified, an alert generates. To disable this alert, set the alert value to **99**.
- Type the maximum amount of hours an employee can work per shift in the **Maximum Punch Time at** field. If an employee works a shift more than the hours specified, an alert generates and the hours stop accumulating for that given shift. To disable this alert, set the alert value to **99**.
- **Alert Day Overtime OT at** triggers an alert before employees reach daily overtime by using the daily overtime value that you set under Overtime Preferences.

Example: If you have Day OT1 set to 8 hours and Alert Day Overtime OT set to 2 hours, an alert posts to the Home page when the employee reaches 6 hours worked for the day.

- **Alert Week Overtime OT at** triggers an alert before employees reach weekly overtime by using the weekly overtime value that you set under Overtime Preferences.

Example: If you have Week OT1 set to 40 hours and Alert Week Overtime OT set to 8 hours, an alert posts to the Home page when the employee reaches 32 hours worked for the week.

- Type the number of minutes to check alerts in the **Check Alerts Every** field. New alerts are checked and posted to the Home page based on the time entered here. To maximize system speed and performance, we recommend setting this value to 10 minutes or more.
- Click **Submit** to save your settings and return to the Home page.

For additional Alert configuration, select Settings | Alert Setup.

Alert Setup

Using the Alert Preferences set earlier, select **Settings | Alerts Setup**, and follow the instructions below to set up Home page and email alerts.

Using the Alert Preferences set earlier, select **Settings | Alerts Setup**, and follow the instructions below to set up Home page and email alerts.

<input checked="" type="checkbox"/>	DESCRIPTION	LIFETIME
<input checked="" type="checkbox"/>	High Hours	1 Day ▼
<input checked="" type="checkbox"/>	Low Hours	1 Day ▼
<input checked="" type="checkbox"/>	Maximum Hours	1 Day ▼
<input checked="" type="checkbox"/>	Approaching Daily Overtime	1 Day ▼
<input checked="" type="checkbox"/>	Approaching Weekly Overtime	1 Day ▼
<input checked="" type="checkbox"/>	Check for Updates	Forever ▼
<input checked="" type="checkbox"/>	Backup Reminder	1 Week ▼
<input checked="" type="checkbox"/>	Punch Notify	1 Hour ▼

- **Enabling/Disabling Alerts:** To disable an alert, deselect the checkbox in the far left column. This prevents the alert from being posted on the Home page
- **Lifetime:** Use the drop-down menus under the Lifetime column to select the amount of time the alert remains on the Home page. After that time, the alert is automatically removed.

Creating Custom Fields

TotalPass offers 10 additional fields for tracking static information in Custom Fields.

In addition, Timecard Reports can be filtered based on the Custom Field values assigned to an employee with Labor Distribution Reports.

Examples:

- **Location**
- **Account**
- **Part-Time / Full-Time Status**

Pay Punch Device Alerts Custom Fields

CUSTOM FIELD PREFERENCES

Title for Field 1: Emergency Contact
Assign Field 1 to: Employee ▼

Title for Field 2: Alternate Phone #
Assign Field 2 to: Employee ▼

ADP Export: Use the Custom Field to track the employee's ADP Payroll ID. Refer to the ADP Export User Guide installed with the ADP Payroll Export for instructions.

Custom Fields values can be added to the following locations.

- **System:** These fields display on the bottom of the Custom Fields page.

- **Employee:** These fields display on the bottom of each employee's Edit Employee page.
- **Department:** These fields display on the bottom of the Edit a Department page

Follow the instructions below to set your Custom Fields.

- Type the title for the custom information in the **Title for Field X** field (X being the field number).
- Select where this custom field should display from the **Assign Field X to** drop-down menu (X being the field number).
- Click **Submit** to save your settings and return to the Home page.
- Go to the new custom field on the page specified and enter information as needed.
- For additional information on generating reports based on the custom field value assigned to an employee, refer to [Chapter 6: Generating Reports](#).

Chapter 3: Setting Up Your Employees

After setting up your pay period and other preferences, set up the employees in the system.

- ✓ Adding employees
- ✓ Setting up automatic lunch deductions

TotalPass P400 comes with a 25-employee limit and can be upgraded to handle up to 250 employees.

Employee List

A list of your employees and their ID numbers are in the Lists Menu under Employees. Click on the column header to sort by that particular column.

EMPLOYEE LIST									
Select All	Select None	Show Inactive	Columns						
				Employees: 45 Active 5 Inactive					
Active	Payroll ID	Display ID	Last Name	First Name	M.I.	Web Punch	Time Remaining Before Overtime		
							Daily	Weekly	Consecutive Days
<input checked="" type="checkbox"/>		0101	Employee 0101				8.00	40.00	7
<input checked="" type="checkbox"/>		0123	Employee 0123				8.00	40.00	7
<input checked="" type="checkbox"/>		0145	Employee 0145				8.00	40.00	7
<input checked="" type="checkbox"/>		0167	Employee 0167				8.00	40.00	6
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>									

Make Employees Inactive

Making an employee inactive removes them from the Employee List and hides the employee data from the reports. Their punch data remains stored in the time clock.

- To make an employee inactive, deselect the checkbox in the far left column, click Submit.
- To select all employees, and make them active, click on Select All.
- To make all employees inactive, click Select None.
- To show inactive employees, click on the Show Inactive option.

Customizing the Columns

- Select the **Columns** link to hide or show columns on the Employee List.
- Click on the **column** header to sort by a particular column.

Select All	Select None	Show Inactive	Columns
			<input checked="" type="checkbox"/> Active
			<input checked="" type="checkbox"/> Payroll ID
			<input checked="" type="checkbox"/> Display ID
			<input checked="" type="checkbox"/> Last Name
			<input checked="" type="checkbox"/> First Name
			<input checked="" type="checkbox"/> M.I.
			<input checked="" type="checkbox"/> Time Remaining Before Overtime
			Employee 0101

Time Remaining Before Overtime

- The Daily column displays the number of hours left in the day before the employee starts earning daily overtime.
- The Weekly column displays the number of hours left in the week before the employee starts earning weekly overtime.
- The Consecutive Days column displays the number of days left in the work week before the employee starts earning consecutive day overtime (when this option is enabled in Pay Preferences).

To edit employee information, click the employee ID number in the Display ID column. This displays the Edit an Employee screen.

Adding Employees

To add your employees individually, select an employee or one of the available employee slots. Follow the instructions below to set up an employee.

Employee Information

- **Payroll ID:** (Optional) Enter the employee's payroll ID # provided by the payroll company. This Payroll ID will be used when generating payroll exports.

Note: This field is not required to be completed when using the QuickBooks Plug-in or ADP Export Utility.

- **First Name:** Enter the employee's first name.
- **Middle Initial:** Enter the first initial of the employee's middle name.
- **Last Name:** Enter the employee's last name.
- **Display Name:** Enter the name that the employee will see at the clock and on reports.

Note: Timecard Reports are sorted by Display Name.

- **Address:** Enter the employee's address. This field is optional.

Employee Settings

- **PIN/Badges:** The employee PIN number is used to clock In or Out at the time clock.
- **Active:** All employees default to an active status. Deselect this checkbox to make the employee inactive and to hide their name from reports.
- **Track Paid Breaks:** Select this box to track the employees time spent in their Paid Breaks.
- **Wage:** Specify a wage the employee is paid.

Entry Method

This option determines the procedure for punching in and out by the employee at the employee time clock. Select the desired method from the drop-down menu.

Review the description of the time clock entry methods below and choose your entry method.

- **Validated:** The employee is required to either punch in or out at the employee time clock. The correct option blinks on the time clock display. The employee is required to press the correct key at that time.

Example: If an employee forgets to punch out the day before, they will be required to punch out first before they can punch in for their current shift. The punch information can be edited

in the software so the proper punch out time and date is recorded on the reports.

- **Non Validated:** In and Out displays under the employee's name at the employee time clock. The employee is required to press the correct key at that time, either **In** or **Out**. Either entry is accepted by the employee time clock.
- **Automatic:** This is also known as "Swipe and Go". After the employee enters their PIN/badge number, the time clock displays the employee name and the message, "Entry Recorded." The employee is not allowed to make any other selections at the time clock. This provides a simple and quick method to punch at the time clock. You cannot make lunch overrides or hours adjustments to these types of punches. Refer to the [Adding a Punch](#) section on page 44 for additional information.

Lunch Time Deduction

- Enable **Automatic Lunch Deduction** to automatically deduct the employee lunch time for the day or the punch pair.

LUNCH TIME DEDUCTION

Automatic Lunch Deduction

Lunch At

Lunch Length

Deduct

Enabled ☐

4.00

Hours

30

Minutes

Per Punch ☐

- In the **Lunch At** field, enter the number of hours the employee is required to work before the lunch period automatically deducts from the employee's shift.
- Enter the amount of time in minutes to deduct for lunch (typically 30 to 60 minutes) in the **Lunch Length** field.
- Deduct:
 - When **Per Punch** is selected the time worked from the last In punch is used to determine whether the **Lunch At** threshold has been met. If an employee goes to break or punches Out before the lunch time is deducted, the Lunch At calculation will start again once the employee has clocked In. Selecting this option will allow lunch time to be deducted multiple times per day.
 - When **Per Day** is selected, the total amount of the employee's hours for the day will be added up to determine whether the **Lunch At** threshold has been met. Lunch deduction will occur once the threshold has been met.

Note: Only one lunch deduction will occur per day when Deduct is set to Per Day. Manually entering a lunch deduction will prevent an automatic lunch deduction from occurring that day.

Delete Employee's Punches

Delete All Punches for this Employee: This is typically used when an employee leaves the company and you want to re-use the employee ID (PIN).

- To delete the employee's punches, click **Delete all punches for this employee**.
- Click **OK**.


Note: Before purging employee punches, we recommend that you save a backup of your data. This allows you to view that employee's data at a later date.

Chapter 4: Clocking In and Out

This section describes employee functionality at the clock including:

- ✓ How to clock In and Out with a PIN, proximity badge, or through a web browser
- ✓ Transfer to break

Time Clock Keypad Functions



- 1. Clock Display**
- 2. Clear** - Returns user to the previous menu option.
- 3. ^ or v** - Used to scroll up or down through menu options.
- 4. Enter** - Selects and saves menu options.
- 5. Supervisor Mode** - Allows supervisor to access advanced time clock terminal options.
- 6. Info** - Displays daily and weekly hourly totals for the employee.
- 7. Break/Dept. Transfer** - Used by the employee to transfer into a Department or Paid Break.
- 8. Built-in RFID Card Reader for scanning Proximity Badges**
- 9. In/Out** - Used by the employee to punch IN or OUT.

Punching In and Out

The employee procedure to punch In and Out at the time clock may vary depending on the entry method selected.

Keypad PIN Entry

Enter the pre-assigned 4-digit PIN and press Enter.

Proximity Badge Entry

For instructions on assigning proximity badges to your employee(s) and for instructions on clocking In/Out using proximity badges, refer to Chapter 8: Alternate Employee Entry Options.

Web Punch Entry

For instructions on Web Punch Entry, refer to Page 39 Web Punch Entry

Tracking Paid Breaks

The TotalPass system allows for better management of employee paid breaks. Tracking paid breaks allows you to better manage the time your employees are taking during their paid break periods.

Note: This option must be activated for each employee, as discussed in Chapter 3: Setting Up Your Employees

To track time that an employee spends on their paid break, the employee must be assigned to the break department and must transfer into the break department.

To transfer into the break department, follow the instructions below. The employee must already be punched In to the employee time clock.

- Enter the assigned PIN/badge number on the time clock terminal, or wave the proximity badge in front of the number pad.
- Instead of pressing Out, press the **Break/Department Transfer** key on the time clock.
- A message stating “*Going To... Break*” displays on the time clock. To clock into break, press **Enter**. This punches the employee out of the work department and into the break department.

To transfer out of the break department and back to work:

- Enter your PIN/badge number at the time clock terminal, or wave the proximity badge in front of the number pad.
- Instead of pressing In or Out, press the **Break/Department Transfer** key on the time clock.
- A message stating *Going To... Break* displays on the time clock. Press **Up** or **Down** to select the work department. To punch out of break and into work, press **Enter**. This punches the employee out of the break department and into the work department.

Chapter 5: Generating Reports

- ✓ Overview of the reporting options
- ✓ Adding and editing punches
- ✓ Entering Holiday and Non-work time

Reports in your application are designed to be intuitive to read and edit.; this creates ease and simplicity when generating your reports on payroll day.

Reports Overview

TotalPass P400 comes with the following standard reports:

- **Attendance Report** displays all employee punch data sorted by date.
- **Timecards Report** displays punches and hours sorted by employee.

Adding a Punch

From a report screen, click Add Punch.

From: 08/14/18 Thru: 08/14/18				Daily - Labor - Exceptions - Refresh							
EMPLOYEE	TIME IN	AT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL	TOTAL	
08/14/18											
0023-Empl 0023	Tue 02:11p E	Work	Tue 10:00p E	30min		7.32				7.32	
0101-Empl 0101	Tue 02:24p E	Work	Tue 10:00p E			7.60				7.60	
Totals: (Format: Hundredths)						14.92				14.92	

Perform the following when adding a punch:

- Confirm or select the correct employee.
- Select the punch type to add from the **Type** drop-down menu.
 - Automatic allows the time clock to select the appropriate punch type.
 - When adding or editing an Automatic punch in the **TIME OUT** column, change the punch type from Automatic to Out, to add a lunch or hours adjustment.
- Click in the **Date** field to use the calendar to select the punch date.
- Type the time for the punch in the **Time** field. The application assumes a.m. unless otherwise specified.
- For In punches, select the department from the **Department** drop-down menu.
- For an Out punch, you have the option to enter an additional lunch deduction. Type the number of minutes for the employee lunch deductions in the **Lunch** field.

Add New Punch

Employee	0023-Empl 0023
Type	In
Date	08/14/18
Time	02:11p ▲▼
At	Work
Note	
	Submit Cancel

- For an Out punch, you have the option to enter an additional time adjustment. Type positive or negative values to adjust time for the shift in the **Adjust** field.
- Type any applicable notes in the **Note** field. You have an additional option to print notes that coincide with each particular punch. This feature is often used to track an event that happened with that punch. A plus sign (+) accompanies that punch.

0023-Sandra

DATE	TIME IN	DEPT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL	TOTAL
01/19/15	Mon 06:00a	Office	Mon 02:30p	30min		8:00				8:00
01/20/15	Tue 06:04a	Office	Tue 02:23p	30min		7:49				7:49
01/21/15	+Wed 09:00a	Office	Wed 06:00p	30min		8:30				8:30
NOTE: Arrived late										
01/22/15	Thu 06:07a	Front Desk	Thu 02:31p	30min		7:54				7:54
01/23/15	Fri 05:55a	Front Desk	Fri 02:31p	30min		7:47	0:19			8:06
Totals: (Format: Minutes)						40:00	0:19			40:19

- Click **Submit** to save your changes.

Adding Non-Work Hours (Holiday and Non-Worked)

A non-work punch is a punch where the employee was not actually working, but using benefit time like holiday or jury duty

Non-work hours can be assigned to one or more employees across one or more days.

Add Non-Work Hours

Perform the following when adding a non-work punch:

- Select **Add Non-Work** from the Timecard report.
- Select the employee(s) from the **Select Employees** list.
- Select the applicable punch type that you want to add from the **Type** drop-down menu.

Select Employees

0023-Empl 0023
0067-Empl 0067
0101-Empl 0101
0145-Empl 0145
0189-Empl 0189
0223-Empl 0223
0267-Empl 0267
0301-Empl 0301
0345-Empl 0345
0389-Empl 0389

Select All

Type **Holiday**

Start Date **08/14/18**

Number of Days **1**

Hours Per Day

The available punch types are:

Submit **Cancel**

- NonWorked** – used for employees working off site or other benefit time.
- Holiday**
- Click in the **Start Date** field and use the calendar to select the date when the non-work hours should begin.
- Type the number of days to assign to the employee(s) in the **Number of Days** field.
- Type the number of hours to assign to the selected employee(s), for each day, in the **Hours Per Day** field.
- Type any applicable notes in the **Note** field. You have an additional option to print notes that coincide with each particular punch. You can use a NOTE to describe the type of non-worked benefit hours used. A plus sign (+) accompanies that punch. Click (+) to make the note visible.
- Click **Submit**, you will be directed to the Add Non-Work Hours Confirmation page.
- Review the information on the Add Non-Work Hours Confirmation page for accuracy.
 - Click **Submit** to save your changes.
 - Click **Cancel** to cancel the transaction.

- Click **Back** to go back to the Add Non-Work page and revise the data.

Editing a Punch

Modifying or editing a punch on the reports is simple.

- Click on the In or Out time you want to edit. Each punch entry on the report is a link that will take you to the **Edit a Punch** window.
- Follow the instructions in the [“Adding a Punch”](#) section to edit your punch data.

Note: All edited and manually entered punches will be flagged on the report with an ‘E’ next to the punch. Refer to [“Setting Your Punch Preferences”](#) for instructions on disabling this option.

TIME IN	DEPT
Mon 07:58a E	Front Desk

edited punch

Using Batch Edits

Batch edits is an option selected in [“Setting Your Device Preferences” on page 16](#).

To use Batch Edits with pop-up windows, follow the instructions below.

- Before editing punches, print the report for the pay period. Review which punches you need to edit.
- In the Report screen, click the applicable punch you want to edit or add.
- The Edit a Punch screen displays in a separate pop-up window.
- Make the desired punch edit, then click **Submit**.
- After editing all of the punches, click **Refresh** in the upper right of the report screen. The edited data displays on the report.

Viewing Additional Reporting Details

Customizing your reports and viewing additional details on a report is uncomplicated.

The blue links in the reports are Web links that allow you to customize or view details of your data. Some reports have additional detail options.

From: 03/07/16 Thru: 03/20/16 Add Punch Add Non-Work				Columns · Summary · Page Break · Daily · Notes · Exceptions · Refresh					
0089-B_Jackson									
DATE	TIME IN	DEPT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL TOTAL
03/07/16	Mon 07:56a	Manufacturing	Mon 04:30p	30min		8:00			8:00
03/08/16	Tue 08:00a	Manufacturing	Tue 04:32p	30min		8:00			8:00
03/09/16	+Wed 08:00a	Manufacturing	Add Punch						
Totals: (Format: Minutes)						16:00			16:00

- Edit Employee Info: Click the employee's name in the Employee column of the report to edit an employee's details.
- Select a Report Time Period: To change the report timeframe, click the date link at the top upper left of the Report screen.

From: 03/07/16 Thru: 03/20/16 Add Punch Add Non-Work Columns Summary Page Break Daily Notes Exceptions Refresh

- Today
- This Week
- This Pay Period

- Yesterday
- Last Week
- Last Pay Period

From: 03/07/16 Thru: 03/20/16

Employee: All

Submit Cancel

DEPT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL	TOTAL
Manufacturing	Mon 04:30p	30min		8:00				8:00
Manufacturing	Tue 04:32p	30min		8:00				8:00
Manufacturing	Add Punch							
				16:00				16:00
				REG	OT1	OT2	HOL	TOTAL
				16:00				16:00

Grand Total: (Format: Minutes)

- o Click the appropriate predefined timeframe link or use the **From** and **Thru** date fields to enter a custom timeframe to run the report.
- o Click **Submit** after entering custom dates.
- **Daily:** This option displays the total hours worked for each day in a report. This is convenient if the employee clocks in and out multiple times during the day.

Note: You can also click the date in the Employee column of the report to view daily totals for a specific day. Click the date again to hide the information.

- Select **Columns** to customize which columns display on the report.
- The report font size will automatically adjust to fit the page.
- The **Labor** option will display the calculated labor cost (pay), entered in the wage field in the Edit an Employee screen.
- **Exceptions:** Click this link to view punches that may require the attention of the payroll manager. Exception types and settings are found under ["Setting Your Alert Preferences \(Requires Upgrade\)"](#). Descriptions of the exception flags are listed below.

H	Punch pair reached the Alert High Hours
L	Punch pair is below the Alert Low Hours
M	Punch pair reached the Alert Maximum Time

Refresh: Click this link to update the report with all recent punch changes.

Using the Attendance Report

To view the **Attendance Report**, go to **Reports | Attendance**. The **Attendance Report** is designed to give you a quick at-a-glance view of your employee's daily attendance. Most companies use this report to view who has clocked In or Out for the day.

Click on the date link in the upper left corner to choose the time period for the report. From the resulting page, you can perform edits.

From: 08/14/18 Thru: 08/14/18 Add Punch Add Non Work Daily Labor Exceptions Refresh

EMPLOYEE	TIME IN	AT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL	TOTAL
08/14/18										
0023 Empl 0023	Tue 02:11p E	Work	Tue 10:00p E	30min		7.32				7.32
0101 Empl 0101	Tue 02:24p E	Work	Tue 10:00p E			7.60				7.60
Totals: (Format: Hundredths)						14.92				14.92

Using the Timecard Report

This report includes reporting options not available on the Attendance Report. The Timecard Report allows you to run a report for one specific employee, or all employees. To view the Timecard Report, go to **Reports | Timecards**.

From: 03/07/16 Thru: 03/20/16
Add Punch
Add Non-Work

Columns · Summary · Page Break · Daily · Notes · Exceptions · Refresh

0089 B_Jackson										
DATE	TIME IN	DEPT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL	TOTAL
03/07/16	Mon 07:56a	Manufacturing	Mon 04:30p	30min		8:04				8:04
03/08/16	Tue 08:00a	Manufacturing	Tue 04:32p	30min		8:02				8:02
03/09/16	+Wed 08:00a	Manufacturing	Wed 04:35p	30min		8:05				8:05
03/10/16	Thu 07:50a	Manufacturing	Thu 04:29p	30min		7:17				7:17
03/11/16	Fri 08:00a	Manufacturing	Fri 04:32p	30min		8:02				8:02
Totals: (Format: Minutes)						39:30				39:30

0002 R_Jimenez

DATE	TIME IN	DEPT	TIME OUT	LCH	ADJ	REG	OT1	OT2	HOL	TOTAL
03/07/16	Mon 07:04a	Service	Mon 03:30p	30min		7:56				7:56
03/08/16	Tue 06:59a	Service	Tue 03:30p	30min		8:01				8:01
03/09/16	Wed 07:03a	Service	Wed 03:30p	30min		7:57				7:57
03/10/16	Thu 07:00a	Service	Thu 03:32p	30min		8:02				8:02
03/11/16	Fri 07:00a	Service	Fri 03:36p	30min		8:04	0:02			8:06
Totals: (Format: Minutes)						40:00	0:02			40:02

Grand Total: (Format: Minutes)						79:30	0:02			79:32
--------------------------------	--	--	--	--	--	-------	------	--	--	-------

Columns ·

☒ Time In
☒ Dept
☒ Time Out
☒ Lunch
☒ Adjust
☒ Regular
☒ Overtime 1
☒ Overtime 2
☒ Holiday
☒ Total
☐ Labor
☒ Jobs

To filter by employee or date, click the date link at the top of the report:

- Click **Summary** at the top of the Timecard Report to display a summary of total hours without the punch detail.
- Click **Page Break** at the top of the Timecard Report to create a page break between employee timecards. This also displays an employee signature line when you print timecards. This option is often used by companies that keep a printed record of employee time and to show employee timecard approval.
- Click **Export** at the top of the report to download the report in comma-delimited (CSV) format. The CSV export comes in two formats.
- **CSV** format includes relevant punch information for importing into payroll applications or editing in Microsoft Excel.
- **CSV (Extended)** format includes additional/internal punch information used for integration with third-party applications.

Chapter 6: Sending to Payroll

TotalPass offers a few options for streamlining your payroll process


- ✓ Creating an export file
- ✓ Sending individual timecards

Create Payroll Export File

At the end of the pay period, compile employee data and transmit to payroll for processing.

The Payroll report option creates a payroll export file for the following platforms:

- Paychex Flex
- Sure Payroll
- Paychex Preview
- Paycom
- Paylocity
- ADP Workforce Now
- QuickBooks Online
- QuickBooks (Pro®, Premier, Enterprise)



PAYROLL

What Do You Want To Do?

Select Your Timeframe

Select Your Export Format

Important:
[Review Employee Timecard](#)

payroll.

- None
- Paychex Flex
- SurePayroll
- Paychex Preview
- Paycom
- Paylocity
- ADP Workforce Now
- QuickBooks Online

The Payroll page allows you to download an export file to your PC or to email a copy of the Timecard report and the export file to one or more recipients. (Email requires the Email Alerts upgrade).

Note: Email functionality requires that the clock is connected via Ethernet and that the SMTP Preferences be set.

To create the export file, go to Payroll | Export Payroll:

- Ensure that each of your employees has an assigned Payroll ID. Employees without a Payroll ID will not be included in the payroll export file.
- Select **Click here** for a List of Employees without IDs.
- Customize the **Payroll ID** for each of the listed employees.
- Select **Create An Export** from the option What Do You Want to Do?
- Select the timeframe from the drop-down menu.
- Select your payroll provider in the **Select your Export Format** field.
 - o Paychex Flex
 - o SurePayroll
 - o Paychex Preview
 - o Paycom
 - o Paylocity
 - o ADP Workforce Now
 - o QuickBooks Online

- Press **Submit**.

Note: You are notified if any employees do not have an assigned Payroll ID. The message and the option to view a list of these employees' displays at the bottom of the Payroll report screen.

QuickBooks Export Payroll process

1. Users can use the Employees and Departments list boxes to filter and choose which employee hours are exported.

Select Your Export Format QuickBooks Online ▼

Select Employees

0155, Aizcorbe, Teddy A, Teddy Aizcorbe
3810, Alvarez, Javielky, Javielky Alvarez
8278, AlvrzFacio, Lanie, Laniel Alvarez Facio
8517, Docteur, Ricknel, Ricknel Docteur

Select All

Select Departments

Break
1060BRICK RUNNER
1060BRICK SUPERV
5600 CONDOMINIUM
ARTECITY
ATRIUM CASHIER
ATRIUM RUNNER
AV HOSP SHUTTLE

Select All

2. Users will be able to review the data before submitting to QuickBooks Online.


Review Data Before Submitting to QuickBooks Online From 2017-12-17 Through 2018-01-05

Time Activities (13 Records)

Transaction Date	Employee Name	Hours	Minutes	Type
2017-12-17	Ricknel Docteur	13	0	Reg
2017-12-18	Javielky Alvarez	8	0	Reg
2017-12-19	Javielky Alvarez	7	30	Reg
2017-12-20	Javielky Alvarez	8	0	Reg
2017-12-21	Teddy A. Aizcorbe	7	30	Reg
2017-12-21	Javielky Alvarez	8	0	Reg
2017-12-22	Teddy A. Aizcorbe	7	30	Reg
2017-12-23	Teddy A. Aizcorbe	7	30	Reg
2017-12-28	Teddy A. Aizcorbe	7	30	Reg
2017-12-29	Teddy A. Aizcorbe	7	30	Reg
2017-12-30	Teddy A. Aizcorbe	7	30	Reg
2018-01-04	Teddy A. Aizcorbe	7	30	Reg
2018-01-05	Teddy A. Aizcorbe	7	30	Reg

Submit Cancel

3. The final confirmation screen will have a total of the time activities exported.



Configuring Payroll

Navigate to Payroll | Configure Payroll

1. Users will be able to configure payroll specific pay/earning codes.
2. This applies to Paylocity, ADP Workforce Now, and QuickBooks Online

CONFIGURE PAYROLL

Select Your Payroll Export Paylocity ▼

+ Regular ▼

Other Options

Export Departments ☒

Export Wages ☒

Submit

QuickBooks Online Configuration

QuickBooks configuration involves connecting to an online QuickBooks account and linking employees between QuickBooks and the time clock, or adding them from one application to the other if they are not yet listed.

1. Within the Configure Payroll screen, select the QuickBooks Online payroll export and then click on the **Connect to QuickBooks** button.

CONFIGURE PAYROLL

Select Your Payroll Export QuickBooks Online ▼

qb Connect to QuickBooks

2. Select a QuickBooks employee and a time clock employee and click on the **Link** button to link them between the two applications.

CONFIGURE PAYROLL

Select Your Payroll Export QuickBooks Online

QuickBooks Employees

Last Name	First Name	Middle Name
Aizcorbe	Teddy	A
Alvarez	Yolanda	
Bebe	Bebe	
Doe	Jean	
ICON Test	ICON Test	
QA	Icon	
Testing	Testing	

Add to Clock

Time Clock Employees

Last Name	First Name	MI	PIN
Abboud Massoud	Raed		1215
Abrante	Jose	I	3807
Aguiar	Andy		0145
Aizcorbe	Teddy	A	0155
Altamirano	Anax		2804
Alvarez	Javielky		3810
Alvarez Facio	Laniel	L	8278

Add to QuickBooks

Link

Linked Employees

QuickBooks Employee Name	Time Clock Employee Name	PIN
No data available in table		

Remove Link

qb Disconnect from QuickBooks

3. Linked employees will be displayed at the bottom in the Linked Employees list box.

CONFIGURE PAYROLL

Select Your Payroll Export QuickBooks Online

QuickBooks Employees

Last Name	First Name	Middle Name
Bebe	Bebe	
ICON Test	ICON Test	
QA	Icon	
Testing	Testing	

Add to Clock

Time Clock Employees

Last Name	First Name	MI	PIN
Abboud Massoud	Raed		1215
Abrante	Jose	I	3807
Aguiar	Andy		0145
Altamirano	Anax		2804
Alvarez Facio	Laniel	L	8278
Angeles	Luis	A	3365
Apolinario Castillo	Orlando	J	4089

Add to QuickBooks

Link

Linked Employees

QuickBooks Employee Name	Time Clock Employee Name	PIN
Jean Doe	Ricknel Docteur	8517
Teddy A Aizcorbe	Teddy A. Aizcorbe	0155
Yolanda Alvarez	Javielky Alvarez	3810

Remove Link

qb Disconnect from QuickBooks

1. Employees that don't have a matching entry in either system can simply be added by highlighting them and clicking on either **Add to Clock**, or **Add to QuickBooks**.
2. Linked employees can be unlinked by highlighting them and clicking **Remove Link**.

Chapter 7: Alternate Employee Entry Options

The TotalPass P400 offers various methods for employees to clock In/Out

- ✓ Keypad with pre-assigned PIN (included)
- ✓ Customized PIN 4-9 digits (not included with time clock, purchase required)
- ✓ Proximity badge (not included with time clock, purchase required)
- ✓ Web Punch Entry (not included with time clock, purchase required)


Using Proximity Badges

Proximity badges use the latest in RFID proximity technology and allow employees to clock In/Out by simply waving the badge in front of the time clock keypad. There are many benefits to using proximity badges including; minimizing buddy punching, quicker clock In, no PIN to memorize, and reduces touching the clock.

Proximity Badges can be purchased in boxes of 10 or 25 badges. These badges also conveniently fit into your employee's wallet or can be hung on a lanyard. Badges can be easily reassigned to a new employee if needed.

Assigning Proximity Badges to an Employee

Proximity Badges are assigned at the employee time clock terminal. Follow the instructions below to assign your proximity badge to an employee.

- Enter into Supervisor Mode at your employee time clock terminal.
 - o Press  on the time clock.
 - o Enter your security code - the default security code is "00 00 00".
- Scroll through the options using **Up** or **Down** until you find the option **Assign Badges** and press **Enter**.
- The time clock display will prompt *Enter ID Number*. Use the keypad to enter the ID number (PIN) of the employee and press **Enter**.
- Wave the badge in front of the time clock keypad (the 6 key is the optimal location to wave the badge). The clock will display **Assigned** when the badge has been assigned to the employee.

The employee can now use the badge to punch In and Out. Repeat the steps above for each employee.

Note: To reassign a currently used badge, select the new employee in the Assign Badges menu, enter the PIN of the new employee, and wave the badge. A Badge Already Assigned message will appear. Press Enter to reassign the badge.

Punching In/Out Using Proximity Badges

Wave the badge next to the keypad of the time clock terminal to punch In or Out. Follow the punch procedure established in ["Punching In and Out"](#).

Web Punch Entry (Web Punch License purchase required)

With the Web Punch upgrade, the TotalPass P400 Time Clock allows you to capture your employees' time anytime, anywhere using a web browser from a device on the network (LAN, WAN) or internet.

For employees or supervisors to access the time clock application remotely over the Internet, additional set up is required. Refer to ["Chapter 12: Configure for Remote Access"](#), for more details.

The Web Punch Time Clock also offers advanced functionality like IP location restrictions and GPS tracking to help better manage your employees' punches.

Locking the Time Clock Terminal Keypad

This feature prevents entering a PIN before clocking In or Out.

- Select **Settings | Preferences**, then click the **Device** tab.
- Under **Device Preferences**, check the **Lock Keypad** checkbox and click Submit. By checking this box, employees are no longer able to punch In or Out using their PIN number.

Setting Up Your Employees for Web Punch

Follow the instructions below to assign the employee to the Web Punch Time Clock.

- Select Lists | **Employee List**.
- Select an employee. The **Edit an Employee** screen displays.
- Check the **Assign to Web Punch** checkbox to enable Web Punch for this employee.
- Type a password for the employee to use when punching In/Out on the Web browser in the **Web Punch Password** field.
- Type the IP address that this employee may punch from in the **Authorized IP Address(es)** field. Leave this field blank to allow the employee to punch from any IP address.
- Check the **Allow Punch from Unauthorized IP** checkbox to allow the employee to punch from an unauthorized IP address, but have those punches flagged on the reports for review.
- Check the **Use Global Authorized IP Address** checkbox to allow an authorized IP address for all employees.
- Click **Submit** to save your settings. Repeat the steps above to assign additional employees to Web Punch entry.

WEB PUNCH TIME CLOCK SETTINGS

Assign to Web Punch	<input checked="" type="checkbox"/>
Web Punch Password	<input type="text" value="1234"/>
Authorized IP Address(es)	<input type="text"/>
Allow Punch from Unauthorized IP	<input type="checkbox"/>
Use Global Authorized IP Address	<input checked="" type="checkbox"/>

WEB PUNCH TIME CLOCK SETTINGS

Assign to Web Punch	<input checked="" type="checkbox"/>
Web Punch Password	<input type="text" value="1234"/>
Authorized IP Address(es)	<input type="text"/>
Allow Punch from Unauthorized IP	<input type="checkbox"/>
Use Global Authorized IP Address	<input checked="" type="checkbox"/>

If you exceed your Web Punch License limit, you will receive an error message stating that you do not have enough Web Punch Licenses available.

Punching In/Out Using Web Punch

Employees assigned to the Web Punch Entry can punch In/Out anytime, anywhere, using a web browser interface.

Follow the instructions below to punch in or out using the Web Punch Time Clock.

- Open the employee time clock **Login** page.

Username/PIN	<input type="text" value="0124"/>
Password	<input type="password" value="....."/>
Tue 2:29 PM	
<input type="button" value="Submit"/>	

- Type the assigned PIN/badge number in the **Username/PIN** field.
- Type the employee's assigned Web Punch password in the **Password** field.
- Click **Submit**. The employee Web Punch screen displays.
- Select the appropriate option (**Punch In**, **Punch Out**, or **Department Change**) to complete your punch.
 - If the employee has the ability to change departments, select the department.
- Click **Confirm**.
 - After punching In or Out, the Web Punch screen lists the employee punch information.
 - o **Week Hrs:** Lists the total hours the employee worked for the week.
 - o **Day Hrs:** Lists the total hours the employee worked for the day.
 - o **Punch Hrs:** Lists the total hours the employee worked for that punch pair.

WEB PUNCH

Current Time: Tue 2:32 PM
Hello Jill Abercrombie, you last punched out on 01/27/15 11:00a.

What do you want to do?
[Punch In](#)
[Log Out](#)

Clocking In/Out using GPS Location Tracking

If an employee clocks In/Out using a web browser, additional punch information is available.

Username/PIN

Password

Tue 2:29 PM

[Submit](#)

Note: A punch that includes GPS location information is flagged with a 'G' on the reports. By clicking on that punch you can view additional information provided by the phone's GPS.

GPS Location

- **Latitude/Longitude:** The location of the employee when they created the punch.
- **Accuracy:** The accuracy of the coordinates given by the GPS.

Example: The accuracy of this punch is up to 372 feet. In other words, the employee was within a 372ft radius of the coordinates given.
- **Speed:** States how fast the employee was traveling when they created the punch.

WEB PUNCH

Current Time: Tue 2:32 PM
Hello Jill Abercrombie, you last punched out on 01/27/15 11:00a.

What do you want to do?
[Punch In](#)
[Log Out](#)

Web Punch IP Address 10.1.10.2
 Web Punch Browser iPhone
 GPS Location **Latitude:** 45.822625 **Longitude:** -122.963483
Accuracy: 541 feet (165.0 meters)
Altitude: 705 feet (214.8 meters)

By using Google Maps integration and clicking on the GPS link, you can view the location of the employee at the time of the punch.

IP Address Restriction

Using IP Address Restriction, you can restrict employees from punching from unauthorized locations. This information can be flagged and tracked on your reports.

IP address restrictions are enforced by setting authorized IP addresses globally (company-wide) and/or by employee.

Setting Authorized IP Addresses Globally

Global Authorized IP Address(es) assigns the IP address that all employees can use. To set this, follow the instructions below.

- Select **Settings | Preferences** and click the **Device** tab.
- In the Global Authorized IP Address(es) field, enter the IP address(es) of the computer (or other web-enabled device) the employees are authorized to punch in/out on.
- The authorized IP address can be listed in the following ways.
 - **Any IP Address:** Leave the field blank to allow employees to punch in/out from any IP address.
 - **Multiple IP Addresses:** Put a comma between the authorized IP addresses to allow the employee to punch from any IP address listed.
Example: 192.168.3.6, 192.168.3.78
 - **Range of IP Addresses:** The employee can punch at computers with an IP address that falls within the 30-45 range.
Example: 192.168.3.30-45
- Click **Submit** to save your changes.

Note: If an employee is not restricted to punch In/Out from the Global Authorized IP Address, uncheck the Use Global Authorized IP Address option in the employee's Edit an Employee screen.

Setting Authorized IP Addresses by Employee

The employee's **Authorized IP Address(es)** field assigns the IP address that a particular employee is authorized to punch in/out. To set the authorized IP address(es), perform the following instructions.

- Go to the **Employee List** and select the employee.
- In the **Authorized IP Address(es)** field, enter the IP Address(es) of the computer (or other web-enabled device) that the employee is authorized to punch In/Out.
- You can list the authorized IP address(es) in the following ways.
 - **Any IP Address:** Leave the field blank to allow employees to punch in/out from any IP address.
 - **Multiple IP Addresses:** Put a comma between the authorized IP addresses to allow the employee to punch from any IP address listed.
Example: 192.168.3.6, 192.168.3.78
 - **Range of IP Addresses:** The employee can punch at computers

with an IP address that falls within the 30-45 range.

Example: 192.168.3.30-45

- Check the **Allow Punches from Unauthorized IP** checkbox to allow employees to punch In/out from an unauthorized IP address. Punches from unauthorized IP addresses are flagged with an **X** on the reports.
- Click **Submit** to save your changes.

Running Reports with Web Punch

On your reports, web punches are flagged with a **W** after the punch time. If a punch comes from an unauthorized IP address, it is flagged with an **X**.

By clicking on the punch, additional information about that punch displays.

- **Web Punch IP Address:** Lists the IP address of the computer/device the employee punched in/out from.
- **Web Punch Browser:** Lists the web browser the employee used while punching in/out.

Chapter 8: Maintaining Your Time Clock

Learn to maintain your time clock for optimal performance

- ✓ Backing up and restoring data to your time clock
- ✓ Removing punches from your system
- ✓ Resetting the time clock passwords

Creating a Data Backup

It is important to make a backup (copy) of your employee time clock data periodically. Backups help ensure that your data is secured on a regular basis and can be restored if necessary. We recommend creating a backup of your time clock data each pay period and prior to performing any updates to your time clock.

Data Backup from the Software Interface

Follow the instructions below to create a backup of your time clock's data:

- To create a backup file, select **Files | Create Backup**.
- Click **Submit** to create a backup in the Save to Backup File screen. Click **Save**.
- A file name is automatically assigned for you. The file name includes the current date for easy reference.


Example: A typical file name might be icon-2020-08-15.db.

- If you prefer a different file name, enter the name in the **File name** field.
- Browse to the directory where you would like to save the file.
- Click **Save**.
- After the download is complete, click **Close**.

Data Backup to a USB Flash Drive

Creating a backup of your data can be simplified by saving your backup to a flash drive — a data storage device with an integrated **USB** interface.

Follow the directions below to create a backup of your time clock data using a USB flash drive.

- Plug the USB flash drive into the bottom of the time clock.
- Enter into **Supervisor Mode**:
 - o Press  on the time clock.
 - o Enter your security code - the default security code is "**00 00 00**".
- Press **Up** or **Down** until the *DOWNLOAD BACKUP* option displays.

- Press **ENTER**.

The clock will display *Backing up data* and then *Backup complete*.

Note: The backup file saved on the USB flash drive is called backup.db. This file can be renamed and transferred to a folder on your main computer.

Restore Time Clock Data Backup

On occasion you may need to restore historical data to your time clock. Follow the instructions below to restore a backup of your time clock data.

Important: Restoring a backup file will **OVERWRITE** the current data on the clock. Create a **CURRENT** backup of your data before attempting to restore and view “historical” data.

Restore a Time Clock Data Backup from the Software Interface


- To restore a backup file, select **Files | Restore Backup**.
- Type your password in the **Current Password** field.
- Click **Browse** and navigate to the location of your backup file.
- Select the file in the **Choose File** window and click **Open**.
- Click **Submit** in the Restore Backup File screen to restore the backup file. A warning message will display reminding you that your current data will be overwritten at the employee time clock.
- Click **OK** to continue. It may take several minutes to restore a backup file. The employee time clock will display a *Please Wait* and then a *Performing Restore* message.
- After the restore is complete, you will be required to log back into the time clock to view the backup information.

Note: The backup is a proprietary file that cannot be used or opened using any other program.

Restore a Time Clock Data Backup from a USB Flash Drive

Restoring a backup of your data is easy using your USB flash drive. Be sure to save a current backup file before restoring another backup. Follow the directions below to restore a backup from a USB drive.

- Copy the backup file data to the root of the USB flash drive.
- Rename the file to **backup.db** and ensure the name is all in lower case letters.
- Connect the storage device to the bottom of the employee time clock.
- Enter **Supervisor Mode** on the employee time clock.

- o Press  on the time clock.
- o Enter in your security code - the default security code is “00 00 00”.
- Press **Up** or **Down** until *RESTORE BACKUP* displays and press **ENTER**.
- If the file is found, Restoring Data, then Performing Restore displays. The time clock reboots.
- After the time clock reboots, log back into the employee time clock software to view your historical data.

Removing Data from Your Time Clock

Before removing punch data from your clock, be sure to save a backup of your existing data.

- Go to **Files | Delete Old Punches**.
- Select a date using the calendar in the **Delete Punches Prior to** field.
- Click **Submit** to remove all punches up to the date specified.

Note: When selecting a date, any data prior to that date will no longer be available as part of your active database.

- Click **Cancel** to go back to the time clock Home page.

Updating Your Time Clock

Occasionally, IconTime releases new updates for your employee time clock. These updates are provided for free and often include new features and improvements.

Note: Before performing updates to your employee time clock, we recommend that you save a backup of your data. Refer to [Creating a Data Backup](#) for instruction on how to do this.

Updating Your Time Clock from the Software Interface

Follow the instructions below to update your TotalPass Time Clock.

- Download the time clock update file from our website to your desktop.
- <http://www.icontime.com/totalpassupdate>
- From the Navigation menu, go to **Files | System Update**.
- In the **System Update** screen, type your time clock password in the **Current Password** field.
- Click **Browse** to locate and select the **update.bin** file in the File Upload screen.
- Click **Open** in the File Upload screen.

- Click **Submit** in the System Update screen.
- A “backup your data” pop-up window displays. If you already created a backup of your data, disregard this message by clicking **OK**. Your time clock starts the update process, then automatically reboots. Wait for this process to complete as it may take up to 15 minutes.
- When rebooting is complete, click **Home** to log back into your time clock.

Updating Your Time Clock Using a USB Flash Drive


Updating your time clock is even faster if you use a USB flash drive.

- Download the time clock update file from our website to the root directory on your storage device.
- <http://www.icontime.com/totalpassupdate>
- Connect the storage device to the bottom of the employee time clock. Your time clock begins the update process and automatically reboots. Wait for this process to complete.
- When the reboot is complete, log back into your time clock.


Auto-Update

Clock Admins and supervisors with System Update permissions will receive a New Update Available notification on the homepage with a recommendation to backup. They will be able to update right from the clock once a local backup file has been created.


New Update Alert



Saving a Backup



Updating Clock



Resetting Your Time Clock Password

Changing Your Time Clock Software Interface Password


You can change the password by going to Settings | Change Password

- Enter your current password in the **Current Password** field.
- Type your new password in the **New Password** field.
- Type your new password again in the **Confirm New Password** field.
- Click **Submit**.

CHANGE PASSWORD

Current Password	<input type="password"/>
New Password	<input type="password"/>
Confirm New Password	<input type="password"/>
	<input type="button" value="Submit"/>

Resetting the Software Interface Password

- Enter into Supervisor Mode:
 - Press  on the time clock terminal.
 - Enter your security code - the default security code is **00 00 00**.
- Scroll through the options using **Up** or **Down** until you find the option **Reset Password** and press **Enter**.

CHANGE PASSWORD

Current Password	<input type="password"/>
New Password	<input type="password"/>
Confirm New Password	<input type="password"/>
	<input type="button" value="Submit"/>

- Press **In** to reset the password or **Out** to cancel.
- Once the password is reset you will receive the message *Password Set Successfully* on the time clock display.
- At the time clock **Login** page enter the default login information, and click **Submit**.
 - o Default Username: admin
 - o Default Password: admin
- Change your password.
 - o Type the default administrator password.
 - o Type your new password.
 - o Type your new password.
 - o Confirm your new password.

Resetting the Supervisor Mode Security Code

The Supervisor Mode security code is set from the software interface. The default supervisor code is 00 00 00. It is recommended you change the default code to a new code using the steps below:

- Select **Settings | Preferences** from the Navigation menu.
- Click the **Device** tab.
- Type the supervisor code in the **Supervisor Code** field. This is required to access Supervisor Mode on the employee time clock terminal.
- Click **Submit** to save your settings.

Chapter 9: Time Clock Terminal Supervisor Mode


Advanced Supervisor Mode Options

- ✓ Customize Network Settings
- ✓ Reset Software Admin Password

Log Into Supervisor Mode

DEVICE PREFERENCES

Supervisor Code ←

- Enter into **Supervisor Mode** at your employee time clock terminal.
 - o Press  on the time clock terminal.
 - o Enter your security code - the default security code is "**00 00 00**".
- Scroll through the options using **Up** or **Down**.
- Press **Enter**, when you find the option you would like to view.
- To exit Supervisor Mode, press **Clear**.

Parent Clock Supervisor Mode Settings

View IP Address

Look up the IP address assigned to the clock. Also allows for assigning a static IP address, subnet mask, gateway, and DNS.

Network Settings

LAN Settings

Set IP Address

Look up the Ethernet IP address assigned to the clock. Also allows for assigning a static IP address, subnet mask, gateway, and DNS.

To assign a static IP address, follow the instructions under ["Assign a Static IP Address to the Time Clock"](#).

- To erase all network settings and revert back to DHCP so that the router will assign the IP address, set the IP address to **000.000.000.000**.

Wi-Fi Settings

Set IP Address

Look up the Ethernet IP address assigned to the clock. Also allows for assigning a static IP address, subnet mask, gateway, and DNS.

- To assign a static IP address, follow the instructions under ["Assign a Static IP Address to the Time Clock"](#) on page 60.
- To erase all network settings and revert back to DHCP so that the router will assign the IP address, set the IP address to **000.000.000.000**.

View Networks

Allows you to view wireless networks in range, connect to a wireless network, or switch to a different wireless network. Refer to the ["Wi-Fi Connection"](#) on page 48 for instructions on connecting wirelessly.

WPS Setup

Allows you to connect to a wireless network using WPS. Refer to page 49 for instructions on using WPS connection.

Assign Badges

This option is used when assigning a proximity badge to an employee. Refer to ["Assigning Proximity Badges to an Employee"](#) on page 34.

Set Date/Time

- From **Supervisor Mode**, scroll through the options using **Up** or **Down** until you find the option **Set Date/Time** and press **Enter**.
- The **Set Date** option displays.
 - The **Month** field flashes. Use **Up** or **Down** to select the current month, and press **Enter**.
 - In the **Day** field, use **Up** or **Down** to select the current day of the month and press **Enter**.
 - In the **Year** field, use **Up** or **Down** to select the current year and press **Enter**.
- The **Set Time** option displays.
 - The **Hour** field flashes. Use **Up** or **Down** to select the current hour and press **Enter**.
 - In the **Minute** field, use **Up** or **Down** to select the current minutes and press **Enter**.
 - In the **AM/PM** field, use **Up** or **Down** to select either **A** for a.m. or **P** for p.m. and press **Enter**.
- Once the new time and date is set, *Date/Time and Set Successfully* displays on the time clock display. You are taken back to Supervisor Mode menu. Press **Clear** to exit Supervisor Mode.

View Serial

Shows the unique serial number assigned to the individual time clock terminal. The serial number is used to activate your 30-day free support trial, verify warranty status, and purchase software upgrades.

View Version

The version number refers to the software version currently installed on your time clock. Refer to [page 41](#) for instructions on Updating Your Time Clock and ensure that your time clock is running the latest version.

Download Backup

This option is used to back up your time clock data. Refer to [“Data Backup to a USB Flash Drive”](#) on [page 39](#).

Restore Backup

This option is used to restore data into your time clock. Refer to [“Restore a Time Clock Data Backup from a USB Flash Drive”](#) on [page 40](#).

Enable Upgrade

This option is used to unlock additional upgrade features in your time clock. Refer to [“Enabling Software Upgrades”](#) on [page 52](#).

Reset Password

If you forget your login password, this option is used to reset your password to default. Refer to [“Changing Your Time Clock Software Interface Password”](#) on [page 43](#).

Erase All Memory

Erasing all memory resets the clock back to factory default. Follow the instructions below to Erase All Memory.

- From Supervisor Mode, scroll through the options using **Up** or **Down** until you find the option **Erase All Memory** and press **Enter**.
- The time clock will display *Erase All Memory* IN=YES CLEAR=NO.
- Press **IN** to confirm and erase all the data in the clock and return it to factory defaults.

Download Log

Downloading a log file is used when you need our support team to help troubleshoot your system.

Chapter 10: Connecting to the Clock

Multiple connection options to access your time clock in no time:

- ✓ Easily connect to your wireless network over Wi-Fi.
- ✓ For a fast and reliable connection, use the included Ethernet cable to connect the time clock to your Network.
- ✓ For simple access from one computer, connect using Direct Connect Ethernet or USB.


Wi-Fi Connection

TotalPass offers a few Wi-Fi connection options, for your convenience:

- Using the Clock Interface
- Using the Software Interface
- Using WPS, for extra fast set up

Connecting Using the Clock Interface


The first time that you turn your time clock on, if it detects a wireless network in range, it will prompt you to connect your time clock to the wireless network. To return to this option, and connect to a wireless network, follow the instructions below.

1. Enter into **Supervisor Mode** at your employee time clock terminal.
 - Press  on the time clock.
 - Enter your security code. The default security code is **00 00 00**.
2. Use the up or down arrows to scroll until you find *Network Settings*.
3. Press **Enter**.
4. Find Wi-Fi Settings.
5. Press **Enter**.
6. Use the up or down arrows to scroll until you find *View Networks*.
7. Press **Enter**. A list of available wireless networks displays.
8. Use the up or down arrows to scroll until you find the appropriate network, then press **Enter**.
9. When prompted, enter the wireless network password using the up or down arrows to find the first character of the password, then press **Enter**.

Note: The default mode for the password is alpha lower case. To change the mode, press the **Department Transfer** icon on the bottom right of the clock's keypad. To erase a character, press **Clear**.


10. Repeat step 9 until all characters of the password have been entered. Connect to the Clock.
11. Press **Enter**. When connected, a confirmation displays with the IP address.
12. Write down the IP address.
13. Open a Web browser on your PC. Type the IP address in the Web browser URL bar, press **Enter**.
14. You should be directed to the time clock Login page.

Connecting Using a WPS Button

1. Enter into **Supervisor Mode** at your employee time clock terminal.
 - Press  on the time clock.
 - Enter your security code. The default security code is **00 00 00**.
2. Use the up or down arrows to scroll until you find *Network Settings*.
3. Press **Enter**.
4. Use the up or down arrows to scroll until you find *Wi-Fi Settings*.
5. Press **Enter**.
6. Use the up or down arrows to scroll until you find *WPS Setup*.
7. Press **Enter**.
8. Use the up or down arrows to scroll until you find *Push*.
9. Press **Enter**. Press the **WPS** key on your wireless router within 2 minutes.
10. When connected, a confirmation displays with the IP address.
11. Write down the IP address.
12. Open a Web browser on your PC. Type the IP address in the Web browser URL bar, press **Enter**.
13. You should be directed to the time clock Login page.

Connecting Using a WPS with PIN

Enable WPS PIN Connection on the Clock

1. Find the WPS PIN on the label on your router.
2. Enter into **Supervisor Mode** at your employee time clock terminal.
 - Press  on the time clock.

- Enter your security code. The default security code is **00 00 00**.
3. Use the up or down arrows to scroll until you find *Network Settings*.
 4. Press **Enter**.
 5. Find *Wi-Fi Settings*, press **Enter**.
 6. Find *WPS Setup*, press **Enter**.
 7. Find *PIN*, press **Enter**.

Connect to the Wireless Network

1. Use the up or down arrows to scroll until you find *View Networks*, press **Enter**.
2. Find your Network in the list, using the up or down arrow, press **Enter**.
3. When prompted, enter the *WPS PIN number* using the keypad, press **Enter**.
4. When connected, a confirmation displays with the IP address.
5. Write down the IP address.
6. Open a Web browser on your PC. Type the IP address in the Web browser URL bar, press **Enter**.
7. You should be directed to the time clock Login page.

Connecting Using the Software Interface

To connect your time clock to the wireless network using the software interface, it must be connected to your network or computer using the Ethernet or USB cable.


1. Log into your time clock software interface, on either a Parent Clock or Child Clock.
2. Go to **Settings | Network Settings**. The Wi-Fi Network Settings screen displays the available wireless networks.
3. Click the appropriate network.
4. Type the password in the available field, then click **Connect**.
5. The network selected appears at the top of the list, with an indication the time clock is “connected” to the wireless network.

Ethernet Connection

Connect your time clock directly to your network for a fast and reliable connection .

1. Plug one end of the Ethernet cable, provided in the package, to an available port on your router, DSL modem or switch.
2. Connect the other end to the Ethernet port on your time clock.
3. Plug the time clock into the power. Wait for the time clock to fully boot up, it will display Enter ID Number.

Note: If there is a wireless network in range, you'll be prompted to connect to the wireless network. Press Clear to cancel and move to step 4.

4. Enter into **Supervisor Mode** at your employee time clock terminal.
 - Press  on the time clock.
 - Enter your security code. The default security code is **00 00 00**.

Chapter 11: Software Upgrades

Available upgrades that will allow your system to expand with your business


- ✓ Increase employee and web punch entry capacity
- ✓ Automate tracking and accruing benefit time
- ✓ Automatically email alerts and backups

Software upgrades can be applied at any time. All software upgrade packs for your TotalPass system can be unlocked immediately by simply entering the software key provided.

Enabling Software Upgrades

To purchase a software upgrade, you will need to provide us with your time clock serial number. You can find the serial number in the About Your Clock page under the Help menu.

Once you have purchased the software upgrade, your reseller will provide you with the 9-digit software upgrade code. Follow the instructions below to complete the software upgrade installation.

- Enter into **Supervisor Mode** at your time clock terminal.
 - o Press  on the time clock terminal.
 - o Enter your security code - the default security code is "**00 00 00**".
- Scroll through the options using **Up** or **Down** until you find the option *Enable Upgrade* and press **Enter**.
- Using the keypad, enter in the 9-digit software upgrade code and then press **Enter**.
- The time clock terminal will display the name of the upgrade.
- Press **Clear** to exit out of Supervisor Mode. Unplug the time clock from the power, plug it back in to reboot the time clock. Once the time clock is fully rebooted, the new upgrade features are ready to use.
- If there is a problem, contact our technical support team at **1-800-847-2232#1** or **support@icontime.com**.

Once the upgrade has been installed, go the next section for instructions on setting up and customizing your new upgrade features.

Employee Capacity Upgrades

The TotalPass P400 comes standard with a 25-employee limit.

You can upgrade the employee capacity of your time clock to the next available level, including: 50, 100, or 250 employees per system.

The Web Punch employee entry allows employees to punch anytime, anywhere using a web browser on your computer or smart phone on a LAN, WAN, or Internet.

Web Punch Time Clock upgrades are offered in packages of 5 employee licenses up to a maximum of 50. Web Punch also offers advanced functionality like IP location restrictions and GPS tracking to help better manage your employee's

punches. Refer to "[Chapter 7: Alternate Employee Entry Options](#)" for instructions on setting up Web Punch.

Benefit Tracking Upgrade

For a one-time fee, the Benefit Tracking upgrade can help increase payroll efficiency and monitor labor costs. Employee licenses for this upgrade can be reassigned as needed and include the following features:

Benefit Tracking and Accruals

- Track and manage Vacation, Sick, and Personal Time benefits.
- Automate maximum accrual amounts, yearly carryover, and borrowing of benefits.

Enhanced Overtime Preferences

Customize overtime multipliers; allows you to pay time-and-a-half, double time, or other custom defined overtime rates.

Revision Zones

Round punch (shift) hours to the start and end times of a specific shift. Employees will not get paid for punching In early or Out late.

Enhanced Overtime Preferences

The additional Overtime options can be found under the Pay tab under Preferences in the Settings menu.

- Consecutive Day OT1 On ____ Days – determines when Consecutive Day Overtime should begin to accumulate.
 - **Example:** If Consecutive Day OT On is set to 6 days, employees will receive Overtime 1 on the sixth consecutive day of work. If the Consecutive Day OT1 After setting is set to 5 hours, the first 5 hours worked on the sixth day are considered straight time and the rest of the hours will be Overtime 1 (OT1).
- Consecutive Day OT2 After - refer to the previous example.

If this entry is set to 8 hours, employees will receive Overtime 2 on the sixth consecutive day of work for any hours over 8 in the day.

Note: Overtime regulations are different for each state and can change. Be sure to confirm your state's labor regulations for overtime and adjust these settings accordingly.

- OT1 Multiplier - enter the pay rate for Overtime 1 (usually 1.5).
- OT2 Multiplier - enter the pay rate for Overtime 2 (usually 2).

Note: Making a change to the overtime preferences will prompt the time clock to restart. This will make the time clock unavailable until it fully reboots.

Non-Worked Hours and Benefit Time (Vacation, Sick, Personal)

The Benefit Tracking and Accruals feature allows you to track and manage Vacation, Sick, and Personal Time benefits.

Customizing Benefit Accrual Rules

Benefit Tracking and Accruals allow you to automate maximum accrual amounts, yearly carryover, and borrowing benefits. Benefit balances are available for each day of an employee's employment, letting you deliver real-time information to managers and employees. Accrual rates and tracking are customized for each employee, which allows for maximum flexibility.

To customize an employee's Benefit Accrual Rules, go to the Edit an Employee screen by selecting the employee name from the Employee List.

ACCRUAL SETTINGS

Accrual Start Date

Accrual Reset Date

Accruals

ACCRUAL NAME	HOURS AVAILABLE	HOURS USED	LAST CALCULATED	YEARLY HOURS	YEARLY MAX	RESET AMOUNT	ALLOW NEGATIVE
Vacation	<input type="text" value="0.00"/>	0.00	12/02/11	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="checkbox"/>
Sick	<input type="text" value="0.00"/>	0.00	12/02/11	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="checkbox"/>
Personal	<input type="text" value="0.00"/>	0.00	12/02/11	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="checkbox"/>

- The Accrual Start Date allows you to set the date when the employee is eligible to begin accruing the benefit.
- If your benefits renew/reset each year, enter the date when this happens in the Accrual Reset Date field.
- If this is your first time setting up accrues and your employee currently has Hours Available or a benefit time balance, enter that balance here.
- Additional hours will be automatically accrued each day according to the value set under Yearly Hours. As the employee uses the accrued benefit, the hours are automatically subtracted.
- The total hours that the employee has used since the Accrue Reset date can be found in Hours Used.
- The Last Calculation displays the date when the benefit accrual balance was last calculated.
- Yearly Hours should be set to the total benefit hours the employee accrues in one year.
- The Yearly Max is the maximum number of benefit hours allowed to accumulate for the benefit each year. If you allow vacation hours to carry over from one year into the next, post the annual earned amount plus the amount allowed to carry over (the cap). If your company employs a "use it or lose it" policy, you should post the annual amount.

Add Non-Work Hours

Select Employees

Type

Start Date

Number of Days

Hours Per Day

Select All

0023-Empl 0023
0067-Empl 0067
0101-Empl 0101
0145-Empl 0145
0189-Empl 0189
0223-Empl 0223
0267-Empl 0267
0301-Empl 0301
0345-Empl 0345
0389-Empl 0389

Note: This field should not be set to zero unless your benefits do no accrue. Setting this value to zero will reset the Yearly Hours to zero each day.

- The Reset Amount is the quantity of hours that an employee is to receive at the beginning of each new accrual year. Most companies would leave this field set to zero.
- If your company allows the employee to borrow benefit hours that they have not yet accrued, check the Allow Negative box.

Using Accrued Benefit Hours (Vacation, Sick, Personal)

Follow the instructions below to use accrued benefit hours for the employee.

- Select **Add Non-Work** from Timecard or other report.
- Select the employee(s) from the **Select Employees** list.

- Select the applicable punch from the **Type** drop-down menu.
- The available punch types are:
 - **NonWorked** (used for applying benefit hours other than the predefined categories below.)
 - **Holiday**
 - **Vacation**
 - **Sick**
 - **Personal**
- Click in the **Start Date** field and use the calendar to select the non-worked starting date.
- Type the number of consecutive non-worked days to assign for the selected employee(s) in the **Number of Days** field.
- Type the number of hours to assign to the selected employee(s) each day in the **Hours Per Day** field.
- Click **Submit**, you will be directed to the *Add Non-Work Hours Confirmation* page.
- Review the information on the *Add Non-Work Hours Confirmation* page for accuracy.
 - Click **Submit** to save your changes.
 - Click **Cancel** to cancel the transaction.
 - Click **Back** to go back to the Add Non-Work page and revise the data.
- If the employee does not have enough accrued time, an error page will appear.

Accrual Summary Report

To generate the Accrual Summary Report, go to the Reports icon and select Accrual Summary from the drop-down menu.

This report lists the total benefit accrual hours available and the hours used in real time, for each employee.

ACCRUAL SUMMARY

ADAME, ALE

Accrual Name	Hours Available	Hours Used
Vacation	20.00	12.00
Sick	8.00	8.00
Personal	8.00	0.00

Revision Zones

After installing the Benefit Tracking upgrade, you can access the Revision Zones by going to Lists | Departments and clicking on the individual department to add revision zones.

- In the **In Revision Start Time** field, enter a time in **hh:mm:a/p** format. For example, 7:30a.
- In the **In Revision End Time** field, enter a time in **hh:mm:a/p** format. For example, 8:00a.

Example: In the example above, if an employee clocks In between 7:30 a.m. and 8:00 a.m., the shift start time rounds to 8:00 a.m.

- In the **Out Revision Start Time** field, enter a time in **hh:mm:a/p** format. For example, 4:30p.
- In the **Out Revision End Time** field, enter a time in **hh:mm:a/p** format. For example, 5:00p.

Example: If an employee clocks Out between the Out Revision Start and End Time, the shift end time rounds to the Out Revision Start Time, which is 4:30 p.m.

Note: Making a change to the revision zones will prompt the time clock to restart. This will make the time clock unavailable until the clock fully reboots.

Email Alerts Upgrade

The TotalPass P400 application allows payroll reports and system alerts to be automatically e-mailed to one or more supervisors. The system will send email alerts according to your set preferences for event such as: approaching overtime, punch notifications, low hours, maximum hours, and backup reminders.

Note: A Network connection is required to use email functionality in the clock.

In addition, backups of your time clock data can be automatically emailed to one or more recipients, daily, weekly or monthly.

Important: To send emails, you must have a SMTP server available. Contact your network administrator to find out if your company has a SMTP server. We recommend using Google's free Gmail account for companies that don't have an available SMTP Server. In order to use this service, you must have a Gmail account.

What is an SMTP Server? An SMTP server works like a postal assistant, handling the sending of emails from an email client to an email server. It receives outgoing mail messages from users and routes them to the intended mail recipients.

Outgoing Email Settings (SMTP Server)

- To assign your SMTP server settings, go to Device Preferences by clicking **Settings | Preferences | Device** find **Email/Backup Preferences**.
- Type your complete SMTP e-mail server address in the **SMTP Server Address** field. If you do not have this information, contact your network administrator or your service provider.
- If you enable SSL, you may need to specify the mail server port by entering a colon and then the port number after the server address.

Example: smtp.gmail.com:587 connects to smtp.gmail.com and uses port 587. If a port number is not defined, default port number 25 is used.

- Check the **Use SSL** checkbox to use data encryption when sending emails. Using SSL may be a requirement for some SMTP server providers and may require that you define the SMTP port.

EMAIL/SMTP PREFERENCES

SMTP Server Address	<input type="text"/>
Use SSL	<input checked="" type="checkbox"/>
Use STARTTLS	<input checked="" type="checkbox"/>
Use Authentication	<input checked="" type="checkbox"/>
Username/Email Address	<input type="text"/>
Password	<input type="password"/>
From Email Address	<input type="text" value="your_time_clock@time"/>
Email Backups To	<input type="text"/>
Send Backups	Monthly ▼

- Check the **Use STARTTLS** checkbox if you are using SSL and your SMTP service provider requires that you first connect to the server using a secure connection.
- Check the **Use Authentication** checkbox if your SMTP server requires a username and password to send e-mails.
- Enter the **Username** or **Email Address** used to access your SMTP service (email account).
- If you checked **Use Authentication**, enter the **Password** of your SMTP service,
- Type the e-mail address you want to display in the **From** field in your e-mail in the **From Email Address** field. The default setting is Your_Time_Clock.
- Enter the email address where you would like a copy of your backups automatically sent to in the **Email Backups To** field.
- Select how often you would like those backups emailed; never, daily, weekly, or monthly. Emails will be sent at 2:30 am.
- Refer to **Error! Reference source not found.** on page 62 to complete the Automatic Backup setup.
- Click **Submit** to save your settings.

For your convenience, configuration settings for the most common SMTP Server providers are located in the following section.

Common SMTP Server Settings

Refer to the list below to find the most common SMTP Servers and their configuration settings. If your Internet Service Provider (ISP) is not on the list below, contact your ISP or Network Administrator for configuration instructions.

Live/Outlook/Live/Hotmail

SMTP Server Address:	smtp.live.com:587
Use SSL:	checked
Use STARTTLS:	checked
Use Authentication:	checked
Username/Email Address:	Account email address (user@hotmail.com)
Password:	account password
From Email Address:	account email address

Gmail

SMTP Server Address:	smtp.gmail.com:587
Use SSL:	checked
Use STARTTLS:	checked
Use Authentication:	checked
Username/Email Address:	Gmail account email address (user@gmail.com)
Password:	Gmail account password
From Email Address:	Gmail account email address

Comcast

SMTP Server Address:	smtp.comcast.net:465
Use SSL:	checked
Use STARTTLS:	un-checked
Use Authentication:	checked
Username/Email Address:	Comcast username
Password:	Comcast account password
From Email Address:	Comcast account email address

Verizon

SMTP Server Address:	outgoing.verizon.net:587
Use SSL:	un-checked
Use STARTTLS:	un-checked
Use Authentication:	checked
Username/Email Address:	Verizon username
Password:	Verizon account password
From Email Address:	Verizon account email address

Apple MobileMe / iCloud

SMTP Server Address:	smtp.mac.com:587
Use SSL:	user preference
Use STARTTLS:	if user selects to use SSL above
Use Authentication:	checked
Username/Email Address:	MobileMe/iCloud username
Password:	MobileMe/iCloud account password
From Email Address:	MobileMe/iCloud account email address

Chapter 12: Configure for Remote Access

You can upgrade your time clock so you can connect to your time clock away from the office to enable:

- ✓ Working from home
- ✓ Multiple locations
- ✓ Employee remote punch

Follow the instructions below to set your time clock up with remote access, using Port Forwarding.

System Requirements

- A Broadband Internet connection (Cable, DSL, T1, etc.) at the location of the clock.
- TotalPass connected to your network by an Ethernet (i.e. CAT5) cable.
- A router with "Port Forwarding" functionality.
- Static public/external IP address, although not required, is highly recommended. Contact your Internet Service Provider for a static public/external IP address.

EMAIL/SMTP PREFERENCES

SMTP Server Address	<input type="text"/>
Use SSL	<input checked="" type="checkbox"/>
Use STARTTLS	<input checked="" type="checkbox"/>
Use Authentication	<input checked="" type="checkbox"/>
Username/Email Address	<input type="text"/>
Password	<input type="password"/>
From Email Address	<input type="text" value="your_time_clock@time"/>
Email Backups To	<input type="text"/>
Send Backups	<input type="button" value="Monthly ▼"/>

If your business performs PCI Security Scanning for credit card processing, setup can be complicated and may be incompatible. Some customers choose to set up a separate network for their credit card processing system.

Note: For a nominal fee, IconTime offers an optional service to assist in setting up port forwarding/remote connection to your time clocks.

Step 1: Set Up the TotalPass on the Local Network

Follow the instructions on the [TotalPass Quick Start Guide](#) to set up your time clock on the Local Network. Once you are able to access the TotalPass software Home page from a PC inside your internal/local network, you are ready to configure the system for remote access.

Step 2: Router Configuration


You will now configure your router for [Port Forwarding](#). Port Forwarding allows computers and other network devices to connect to a specific computer or service within a private local area network (LAN), through the Internet.

These instructions include general guidelines for configuring a router for Port Forwarding. Actual steps required may vary with each router. For specific instructions on your particular router, please contact the router's manufacturer.

Note: For instructions on configuring your specific router, go to the website www.portforward.com and select your router brand and model.

Assign a Static IP Address to the Time Clock

In order for Port Forwarding to work correctly, assign a static IP address to the time clock along with the subnet mask, gateway address and DNS address. Your Network Administrator should be able to provide you with this information.

- Determine an available IP address to be assigned to the time clock.
- Enter into Supervisor Mode at your employee time clock terminal.
 - o Press  on the time clock.
 - o Enter your security code - the default security code is **00 00 00**.
- Scroll through the options until you find the option Network Settings - press **Enter**.
- To set a LAN static IP address, press Enter on the LAN Settings option. To set Wifi static IP address, scroll down to the Wifi Settings option and press **Enter**.
- The current IP address of the clock will appear. Press **Enter** again.
- Enter the desired IP address including leading zeros. Press **Enter**.

Example: 192.168.004.155

- Enter the Subnet Mask - press **Enter**.

Example: 255.255.255.000

- Enter the Gateway address - press **Enter**.

Example: 192.168.004.001

Note: If you are unsure of the gateway address, it is typically the same IP address as your router.

- Enter the DNS address of your network - press **Enter**.

Example: 192.168.004.001

- Press **Clear** to exit out of Supervisor Mode.

Open a Web browser on a computer in the same local network. In the address bar, type in the IP address of the clock to verify that you can log into the time clock.

Set Up Port Forwarding on the Router

These instructions are general guidelines for configuring a router for [Port Forwarding](#). Actual steps required may vary with each router. For instructions on configuring your specific router, go to the website www.portforward.com and select your router brand and model, or contact your router's manufacturer.

If you are using both a router and a cable modem router/DSL modem router, port forwarding must be configured on both the router and cable modem router/DSL modem router. Alternatively you may contact your ISP to disable the router function on your cable modem router/DSL modem router so that you only need to setup port forwarding on your main network router.

- Open your preferred web browser. Enter the internal/local IP address of your router in the address bar.

Examples: 192.168.1.1 and 192.168.0.1

Note: If you do not know your routers internal/local IP address, refer to [How To Find Your Routers IP Address](#) guide.

- Enter the router's username and password. Below are some default router logins
- Linksys Router – “admin” for both username and password
- Netgear Router – “admin” for username and “password” for password
- D-Link Router – “admin” for username and (leave blank) for the password
- 3Com Router – “admin” for both username and password
- Microsoft Broadband – “admin” for both username and password
- Look for a tab with a name like, “Port Forwarding” or “Applications and Gaming”. Each router is different, if you are unable to find these settings, refer to your router's instruction guide.
- Next, enter port **80** as the desired port. If port 80 is unavailable, you may enter port **9844** as an alternative.
 - o If your router asks you whether to open ports for TCP or UDP select **TCP** or **both**.
 - o Some routers offer port range option, such as; from port ___ to port ___. Enter the same number into both fields.

Ext.Port	Protocol TCP	Protocol UDP	IP Address	Enable
80 To 80	<input checked="" type="checkbox"/>	<input type="checkbox"/>	192.168.1.100	<input checked="" type="checkbox"/>

- Next, enter the static IP address assigned to the clock.
- If there is a checkbox to “enable” the port forwarding rule, be sure to check the box.
- Make sure you click on the **Save Settings** button, or your changes will not take effect.

Note: You may need to reboot the router for changes to take effect.

Step 3: Connect to Your TotalPass Clock over the Internet

After your router is properly configured on port 80 or port 9844, follow the steps below to connect to the clock through the Internet.

- Look up your external/public IP address in one of the following ways; (skip to step 2 if you already know the external/public IP address provided by your ISP)
 - o On a computer on the same network as your clock, go to www.ipchicken.com. Your external/public IP address will be displayed on the page.

- o Use the Port Forwarding Tester link below to verify if port 80 or port 9844 is open. If the port is not open, there is a setup issue on the clock or your router, remote access will not be available: <http://www.yougetsignal.com/tools/open-ports/>
- From the remote location, type the external/public IP address into a browser's address bar.
- If you opened port 80, simply enter the external/public IP address into the address bar.
- **Example:** http:// 68.213.205.154
- If you are forwarding to port 9844, log onto the time clock using your external/public IP address followed by **:9844**.

Example: http://68.213.205.154:9844

Remote Connection Frequently Asked Questions

Q. I have multiple locations, not connected over a Network (LAN). How do I connect a Child Clock to the Parent Clock at my main office?

A. To connect the Child Clock to the Parent Clock remotely over the Internet, you must forward an additional port, **Port 10923**.

Q. What port do I forward if SSL Data Encryption is enabled?

A. To access the time clock application remotely, while using the SSL data encryption option, forward to **Port 443**. Do not use Port 80.

Q. My Internet Service Provider will not provide me with a Static external/public IP address. Are there other options?

A. If you are unable to get a static external/public IP address from your ISP, you have two options:

- Use the dynamic external/public IP address. If this IP address changes, you will need to use the new address in a remote web browser.
- Use a 3rd party dynamic DNS service provider.

Dynamic DNS allows you to use the same assigned name as a web link in your web browser without concern about the actual public IP address of the router.

List of Dynamic DNS Service Providers:

- dyn.com
- no-ip.com
- dnshdynamic.org
- changelP.com

Troubleshooting Remote Connection Problems


If you are unable to connect to your time clock using the external/public IP address

you will need to troubleshoot your connection and configuration.


- Restart your router.
- If you are using both a router and a cable modem router/DSL modem, ensure that port forwarding has been configured on both the router and cable modem router/DSL modem router.
- The cable modem router/DSL modem router must port forward to the local static IP address assigned to the secondary router.
- Alternatively you may contact your ISP to disable the router function on your cable modem router/DSL modem router.
- Ensure that a static internal IP address has been assigned to the clock along with the proper subnet mask, DNS address, and gateway address. Reboot the time clock to ensure any IP address changes take effect.
- Make sure port forwarding has been setup correctly in the router.
- Make sure that the correct external/public IP address is entered in the web browser.
- Make sure another device on the network is not using the same IP address as the time clock.
- Check the filter settings on the router to be sure that it is not interfering with the connection.
- Use an open port checker, like www.yougetsignal.com to check your external IP address and detect the correct open ports on your network.

For additional troubleshooting steps refer to www.portforward.com. Select your router by model name and number for specific port forwarding instructions.

Standard Remote Connection Setup Diagram



Connect Clocks Remotely with Multi-clock Diagram



Warranty Information

IconTime, INC., a Paychex Company

Notice: The information contained in this document is subject to change without notice.

IconTime MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IconTime shall not be liable for errors contained herein, or for incidental consequential damages in connection with the furnishing, performance, or use of this material.

ONE-YEAR LIMITED WARRANTY

IconTime, INC. offers the original purchaser a warranty for **One (1) Year on Parts and Labor**.

IconTime will repair and exchange parts for your unit free of charge in the USA in the event of a defect in materials or workmanship, as follows:

PARTS

New or comparable rebuilt parts in exchange for defective parts for one (1) year beginning on the date of delivery.

LABOR

Mail-in service for One (1) year beginning on the date of delivery.

SERVICE

If adjustments or repair are required, purchaser must contact our customer service department within the warranty period detailing the request. The purchaser must provide model, serial number, and a copy of original purchase. If IconTime decides a product requires service, IconTime will issue a Return Material Authorization Number (RMA). Products may be shipped to IconTime adequately insured, in their original packaging or equivalent, with shipping charges prepaid. Risk of loss or damage during shipping to IconTime is the sender's responsibility. Once we receive the equipment, it will be inspected, repaired as needed, tested, and returned via standard ground shipping to the purchaser. Return shipping costs of the repaired or replaced unit will be paid by IconTime.

This warranty is extended only to the original purchaser. A purchase receipt or other proof of date of original purchase will be required before warranty work is rendered.

This warranty only covers failures due to defects in materials or workmanship that occur during normal use. It does not cover failures due to damage which occurs in shipment, or failures which are caused by products not supplied by IconTime, or failures which result from accident, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, modification or service by anyone other than a factory service center, or damage that is attributable to acts of God.

No warranty is given for damages caused by external wiring indicating improper connection to power supply or line wiring, or for damages caused by spikes, power surges, brown outs, lightning, static electricity, or radio waves. Surge protectors are readily available to enhance and protect equipment performance following initial installation.

IconTime SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. DURATION OF IMPLIED WARRANTIES, IF ANY, IS LIMITED TO ONE (1) YEAR. Some states do not allow the exclusion of limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. If a problem with your IconTime unit develops during the warranty period, contact IconTime SERVICE DIVISION, at the address below.

There are no other express warranties except as listed above.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of the document may be photocopied, reproduced, or translated to another language without the prior written consent of IconTime, Inc.

Copyright © IconTime, INC. 2009-2020

All other trademarks belong to their respective owners.

IconTime Systems
9000 SW Gemini Drive, Bldg. 8
Beaverton, Oregon 97008

800.847.2232

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules.

These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested for compliance with the FCC criteria.